

Troubleshooting Hardware and Booting Problems

This chapter provides procedures for troubleshooting hardware and booting problems. Although this chapter provides specific procedures for some Cisco products, always refer to your hardware installation and maintenance publication for more detailed information about your specific platform, including descriptions of specific LEDs, configuration information, and additional troubleshooting information.

This chapter begins with the following sections:

- **Booting the Router**—Provides a brief overview of the system initialization process
- **Cisco 7500 Series Startup**—Describes hardware and boot process troubleshooting for Cisco 7500 series routers
- **Cisco 7000 Series Startup**—Describes hardware and boot process troubleshooting for Cisco 7000 series routers
- **Cisco 4000 and Cisco 3000 Series Startup**—Describes hardware and boot process troubleshooting for Cisco 4000 and Cisco 3000 series routers
- **Cisco 2500 Series Startup**—Describes hardware and boot process troubleshooting for Cisco 2500 series routers
- **Cisco 2000 Series Startup**—Describes hardware and boot process troubleshooting for Cisco 2000 series routers
- **Catalyst 5000 Series Startup**—Describes hardware and boot process troubleshooting for Catalyst 5000 series LAN switches
- **Catalyst 3000 Series Startup**—Describes hardware and boot process troubleshooting for Catalyst 3000 series LAN switches
- **Catalyst 2900 Series Startup**—Describes hardware and boot process troubleshooting for Catalyst 2900 series LAN switches
- **Catalyst 1600 Token Ring Switch Startup**—Describes hardware and boot process troubleshooting for Catalyst 1600 Token Ring LAN switches
- **LightStream 2020 Startup**—Describes hardware and boot process troubleshooting for LightStream 2020 ATM switches
- **Testing and Verifying Replacement Parts**—Provides suggested actions when swapping router hardware

The remaining sections describe symptoms, problems, and solutions for Flash boot, netboot, ROM boot, and other bootup problems.

- Router Fails to Boot from Flash Memory
- Vector Error Occurs When Booting from Flash Memory
- Router Partially Boots from Flash and Displays Boot Prompt
- Router Cannot Netboot from TFTP Server
- Router Cannot Netboot from Another Router
- Timeouts and Out-of-Order Packets Prevent Netbooting
- Invalid Routes Prevent Netbooting
- Client ARP Requests Time Out during Netboot
- Undefined Load Module Error When Netbooting
- Router Hangs after ROM Monitor Initializes
- Router Is Stuck in ROM Monitor Mode
- Scrambled Output When Booting from ROM
- Local Timeouts Occur When Booting from ROM
- Unresponsive Terminal Connection to Unconfigured Access Server

Booting the Router

Cisco routers can initialize the system (boot) in any of four different ways:

- Netboot—Routers can boot from a server using the Trivial File Transfer Protocol (TFTP), the DEC Maintenance Operation Protocol (MOP), or the remote copy protocol (rcp) across any of the supported media types (such as Ethernet, Token Ring, FDDI, High-Speed Serial Interface [HSSI], and serial lines)
- Flash memory—Routers can boot from Flash memory, a nonvolatile storage medium that can be electrically erased and reprogrammed
- ROM—Routers can boot a system from built-in read-only memory (ROM)
- PC Flash memory card—Routers can boot from a removable Flash memory card

This section provides general information about router booting. The following topics are covered in this section:

- Netbooting Tips
- Fault-Tolerant Boot Strategies
- Timeouts and Out-of-Order Packets
- Information for Technical Support

Netbooting Tips

During netbooting sessions, routers behave like hosts: they route via proxy ARP, Serial Line Address Resolution Protocol (SLARP) information, Internet Control Message Protocol (ICMP) redirects, or a default gateway. When netbooting, routers ignore dynamic routing information, static IP routes, and bridging information. As a result, intermediate routers are responsible for handling ARP and User Datagram Protocol (UDP) requests correctly. For serial and HSSI media, ARP is not used.

Before netbooting from a server, you should **ping** the server from the ROM software. If you cannot **ping** the server, follow the procedures described in the section “Router Cannot Netboot from TFTP Server,” later in this chapter. If you still cannot **ping** the server, there is probably a server configuration or hardware problem. Refer to your TFTP server documentation or contact your technical support representative for assistance.

Fault-Tolerant Boot Strategies

Although netbooting is useful, network or server failures can make netbooting impossible. After you have installed and configured the router’s Flash memory, configure the boot sequence for the router to reduce the impact of a server or network failure. The following order is recommended:

- 1 Boot an image from Flash memory.
- 2 Boot an image using a netboot.
- 3 Boot from a ROM image.

Following is an example of how to configure a router with a fault-tolerant boot sequence.

```
goriot# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
goriot(config)# boot system flash gsxx
goriot(config)# boot system gsxx 131.108.1.101
goriot(config)# boot system rom
goriot(config)# ^Z
goriot#
%SYS-5-CONFIG_I: Configured from console by console
goriot# copy running-config startup-config
[ok]
goriot#
```

Using this strategy, a router has three sources from which to boot: Flash memory, netboot, and ROM. Providing alternative sources can help to mitigate any failure of the TFTP server or the network.

Note The configuration register must be set to allow ROM image booting after failed netbooting attempts. For more information, refer to the hardware configuration manual for your platform.

Timeouts and Out-of-Order Packets

When netbooting, a client might need to retransmit requests before receiving a response to an ARP request. These retransmissions can result in timeouts and out-of-order packets.

Timeouts (shown as periods in a netbooting display) and out-of-order packets (shown as uppercase Os) do not necessarily prevent a successful netboot. It is acceptable to have either or both of these occur during the process.

The following examples show console output from netbooting sessions that were successful even though timeouts and out-of-order packets occurred (exclamation points represent successfully received packets):

```
Booting gs3-bfx from 131.108.1.123: !!!!!!!!!!!!!!!!!!!!!!!!!!!!!
```

```
Booting gs3-bfx from 131.108.1.123: !O.O!!!!!!!!!!!!!!!!!!!!!!!!!!!!
```

If a netboot generates excessive out-of-order packets and timeouts, problems might result. These problems are discussed later in this chapter.

Information for Technical Support

If you cannot resolve your booting problem using the procedures outlined in this chapter, collect the following information for your technical support representative:

- ROM images (use the **show version** EXEC command)
- Programmable ROM labels
- NVRAM configurations for client and adjacent routers
- Debugging output from adjacent routers using the following privileged EXEC commands:
 - **debug ip packet**
 - **debug arp**
 - **debug ip udp**
 - **debug tftp**

For more information about these **debug** commands, refer to the *Debug Command Reference* publication.

Cisco 7500 Series Startup

When you start up a Cisco 7500 series router, the following should occur:

- The AC (or DC) OK LED should go on immediately and should remain on as long as the system is receiving power
- The blower should be operating
- The Route-Switch Processor (RSP) and front-panel Normal LEDs should go on (to indicate normal system operation) and should remain on during system operation; the CPU Halt LED should remain off
- The Enabled LED on each interface processor should go on (to indicate that the RSP has completed initialization of the interface processor)

When the system has initialized successfully, the system banner (which should look similar to the following example) should be displayed on the console screen. If it is not displayed, make sure that the console terminal is properly connected to the RSP console port and that the terminal is set correctly.

```
System Bootstrap, Version 4.6(5), SOFTWARE
Copyright (c) 1986-1995 by cisco Systems
RSP2 processor with 16384 Kbytes of memory
### [...] ###
F3: 2012356+47852+194864 at 0x1000
      Restricted Rights Legend
Use, duplication, or disclosure by the Government is
subject to restrictions as set forth in subparagraph
(c) of the Commercial Computer Software - Restricted
Rights clause at FAR sec. 52.227-19 and subparagraph
(c) (1) (ii) of the Rights in Technical Data and Computer
Software clause at DFARS sec. 252.227-7013.
      cisco Systems, Inc.
      170 Tasman Drive
      San Jose, CA 95134
GS Software (RSP-K), Version 10.3(571) [fc3], RELEASE SOFTWARE
Copyright (c) 1986-1995 by cisco Systems, Inc.
[...]
Press RETURN to get started!
```

If problems occur, try to isolate the problem to a specific subsystem. The Cisco 7500 series routers have the following subsystems:

- Power subsystem—Power supplies, external power cable, and backplane
- Cooling subsystem—Depending on your system, includes the following:
 - Cisco 7505: Fan-tray, fan-tray spare with six individual fans, and fan control board
 - Cisco 7507: Chassis blower
 - Cisco 7513: Blower module, including blower, blower-speed control board, front-panel LEDs, and the module itself
- Processor subsystem—Depending on your system, includes all interface processors and either the RSP1 or the RSP2

Troubleshooting the Power Subsystem

- Step 1** Check to see if the blower is operating and LEDs on the processor modules are on. If the blower and LEDs are on but the Power Supply LED is off, there is probably a faulty Power Supply LED.
- Step 2** Make sure the power switch is set correctly to the on position.
- Step 3** Make sure the power source, power cable, and power supply are functioning correctly. Swap parts to see if one of the components is faulty.
- Step 4** Ensure that the blower module is seated properly. Make sure that the blower control board edge connector is inserted fully in the backplane socket.

Troubleshooting the Cooling Subsystem

- Step 1** Check to see if the blower is operating when you start up the system. If the blower is not operating, there might be a problem with the blower or the +24 V DC power:
- If the Output Fail LED is on, there might be a problem with the +24V DC supply to the blower or fan tray at either the power supply or the blower control board.
 - If the blower is not operating and the Output Fail LED is off, ensure that the blower module is seated properly. Ensure that the blower control board edge connector is inserted fully in the backplane socket.
- Step 2** If the system and blower start up but shut down after about two minutes, one or more fans might have failed or might be operating out of tolerance. You will probably see an error message similar to the following:
- ```
%ENVM-2-FAN: Fan has failed, shutdown in 2 minutes
```
- If the blower or the blower control board fails, you must replace the blower module.
- Step 3** If you see the following message at startup, the system has detected an overtemperature condition or out-of-tolerance power inside the chassis:
- ```
Queued messages:  
%ENVM-1-SHUTDOWN: Environmental Monitor initiated shutdown
```
- If an environmental shutdown results from an out-of-tolerance power condition, the Output Fail LED will go on before the system shuts down.
- This message might also indicate a faulty component or temperature sensor. Before the system shuts down, use the **show environment** or **show environment table** commands to display the internal chassis environment.
- Step 4** Ensure that heated exhaust air from other equipment is not entering the inlet vents, and that there is sufficient clearance around the chassis to allow cooling air to flow.

Troubleshooting the Processor Subsystem

- Step 1** Check the RSP LEDs. If no LEDs come on, ensure that the power supplies and blower are functioning properly.
- Step 2** Check the seating of the RSP. If the RSP is not seated properly it will hang the system.
- Step 3** If the RSP CPU Halt LED is on, the system has detected a processor hardware failure. Contact a technical support representative for instructions.
- Step 4** Check to see if the RSP Normal LED is on, indicating that the system software has initialized successfully and the system is operational.
- Step 5** Check the Enabled LED on each interface processor. This LED should go on when the RSP has initialized the interface processor.
- Step 6** If the Enabled LED on an individual interface processor is off, the interface processor might have pulled away from the backplane. If the interface processors are not seated properly they will hang the system.

Cisco 7000 Series Startup

When you start up a Cisco 7000 series router, the following should occur:

- The DC OK LED should go on and should remain on as long as the system is receiving source power
- The fans should be operating
- The Route Processor (RP) Normal LED should go on and stay on to indicate normal system operation; the Halt CPU LED should remain off
- The Enabled LED on the Switch Processor (SP) or Silicon Switch Processor (SSP) and each interface processor should go on when the RP has completed initialization of the interface processor or SP (or SSP) for operation

When the system has initialized successfully, the system banner (which should look similar to the following example) should be displayed on the console screen. If it is not displayed, make sure that the console terminal is properly connected to the RP console port and that the terminal is set correctly.

```
System Bootstrap, Version 4.6(5), SOFTWARE
Copyright (c) 1986-1995 by cisco Systems
RP1 processor with 16384 Kbytes of memory
### [...] ###
F3: 2012356+47852+194864 at 0x1000
```

Restricted Rights Legend

```
Use, duplication, or disclosure by the Government is
subject to restrictions as set forth in subparagraph
(c) of the Commercial Computer Software - Restricted
Rights clause at FAR sec. 52.227-19 and subparagraph
(c) (1) (ii) of the Rights in Technical Data and Computer
Software clause at DFARS sec. 252.227-7013.
```

```
cisco Systems, Inc.
170 West Tasman Drive
San Jose, California 95134-1706
```

```
GS Software (GS7), Version 10.3(1) [fc3], RELEASE SOFTWARE
Copyright (c) 1986-1995 by cisco Systems, Inc.
```

```
RP1 (68040) processor with 16384K bytes of memory.
[...]
```

```
Press RETURN to get started!
```

If problems occur, try to isolate the problem to a specific subsystem. The Cisco 7000 series routers have the following subsystems:

- Power subsystem—Power supplies, fans, external power cable, and internal power harness that connects to the backplane
- Cooling subsystem—Depending on your system, includes the following:
 - Cisco 7000: Chassis blower
 - Cisco 7010: Fan tray assembly, including six individual fans, fan control board, and the tray itself
- Processor subsystem—Includes the RP, SP (or SSP), and all interface processors

Troubleshooting the Power Subsystem

- Step 1** Check to see if the DC OK LED is on.
- Step 2** If the LED is not on but the fans are operating and LEDs on the processor modules are on, the Power Supply LED might be faulty.
- Step 3** If the LED is not on and there is no other activity, make sure the power switch is fully in the on position.
- Step 4** Make sure the power source, power cable, and power supply are functioning correctly. Swap parts to see if one of the components is faulty.
- Step 5** Ensure that the fan tray is seated properly. Make sure the fan control board edge connector is inserted fully in the backplane socket.

Troubleshooting the Cooling Subsystem

- Step 1** Check to see if the fans are operating.
- Step 2** If the fans are not operating and the DC OK LED is off, there might be a problem with the +24V DC power.
- Step 3** Ensure that the fan tray is seated properly. Make sure that the fan control board edge connector is inserted fully in the backplane socket.
- Step 4** If the system and the fans start up but shut down after about two minutes, one or more fans has failed or is operating out of tolerance. You will see an error message similar to the following:


```
%ENVM-2-FAN: Fan array has failed, shutdown in 2 minutes
```


If one or more fans or the fan control board fails, you must replace the fan tray.
- Step 5** If you see the following error message, the system has detected an overtemperature condition or out-of-tolerance power inside the chassis:


```
Queued messages:  
%ENVM-1-SHUTDOWN: Environmental Monitor initiated shutdown
```


If an environmental shutdown results from an out-of-tolerance power condition, the DC OK LED will go off before the system shuts down.

This message could also indicate a faulty component or temperature sensor. Use the **show environment** or **show environment table** command to display the internal chassis environment.
- Step 6** Make sure that heated exhaust air from other equipment is not entering the inlet vents, and that there is sufficient clearance around the chassis to allow cooling air to flow.

Troubleshooting the Processor Subsystem

- Step 1** Check to see if the RP LEDs come on when system power is turned on.
- Step 2** If none of the RP LEDs come on, make sure that both the fan and power supply are functioning properly.
- Step 3** If the power supply and fans appear operational but none of the RP LEDs are on, an improperly connected RP, SP (or SSP), or interface processor might have hung the bus.

- Step 4** If the SP (or SSP) Enabled LED is off but any of the RP LEDs are on, make sure the SP (or SSP) is seated in its slot properly.
- Step 5** Check to see if the Boot Error LED is on. If it is, the system software is unable to start up. If you have a spare RP with the system software ROMs installed, replace the installed RP with the spare to see if the system will boot.
- Step 6** Check to see if the RP CPU Halt LED is on. If it is, the system has detected a processor hardware failure. Contact a technical support representative for more information.
- Step 7** Check to see if all interface processor Enabled LEDs are on.
- Step 8** If the Enabled LED on an individual interface processor is off, make sure that the interface processor has not pulled away from the backplane.

Cisco 4000 and Cisco 3000 Series Startup

When you start up a Cisco 4000 series or a Cisco 3000 series router, the following should occur:

- The System OK LED should come on and stay on as long as power is supplied
- The fans should be operating

When the system has initialized successfully, the system banner (which should look similar to the following example) should be displayed on the console screen.

```
System Bootstrap, Version 4.14(9), SOFTWARE
Copyright (c) 1986-1994 by cisco Systems
4000 processor with 16384 Kbytes of main memory
```

```
Loading xx-j-mz.112-0.15 at 0x4A790, size = 3496424 bytes [OK]
F3: 8988+3487404+165008 at 0x12000
Self decompressing the image : ###[...]#### [OK]
```

Restricted Rights Legend

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) of the Commercial Computer Software - Restricted Rights clause at FAR sec. 52.227-19 and subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS sec. 252.227-7013.

```
cisco Systems, Inc.
170 West Tasman Drive
San Jose, California 95134-1706
```

```
Cisco Internetwork Operating System Software
IOS (tm) 4000 Software (XX-J-M), Version 11.2(0.15), BETA TEST SOFTWARE
Copyright (c) 1986-1996 by cisco Systems, Inc.
Compiled Wed 03-Jul-96 01:21 by susingh
Image text-base: 0x00012000, data-base: 0x006F6494
```

```
cisco 4000 (68030) processor (revision 0xA0) with 16384K/4096K bytes of memory.
Processor board ID 5007155
G.703/E1 software, Version 1.0.
```

```
Bridging software.  
SuperLAT software copyright 1990 by Meridian Technology Corp).  
X.25 software, Version 2.0, NET2, BFE and GOSIP compliant.  
TN3270 Emulation software (copyright 1994 by TGV Inc).  
Basic Rate ISDN software, Version 1.0.  
2 Ethernet/IEEE 802.3 interfaces.  
4 Serial network interfaces.  
8 ISDN Basic Rate interfaces.  
128K bytes of non-volatile configuration memory.  
4096K bytes of processor board System flash (Read/Write)
```

Press RETURN to get started!

If problems occur, try to isolate the problem to a specific subsystem. The Cisco 4000 and Cisco 3000 series routers have the following subsystems:

- Power subsystem—This subsystem includes the power supply and the wiring
- Cooling subsystem—This subsystem includes the blower assembly, which should come on when power is applied
- Network processor modules—This subsystem includes all NPMs installed in the router chassis
- System cables—This subsystem includes all of the external cables that connect the router to the network

Troubleshooting the Power and Cooling Subsystems

Step 1 Check to see if the blower is operating. If it is not, check the AC power input, AC power source, router circuit breaker, and the power supply cable.

Step 2 If the system shuts down after being on a short time, check the power supply. If the power supply appears operational, the router might have shut down due to overheating. Check the console for error messages similar to the following:

```
%SYS-1-OVERTEMP: System detected OVERTEMPERATURE condition. Please resolve cooling  
problem immediately!
```

Make sure that the fans are working and that there is no air blockage to cooling vents.

Step 3 If the system partially boots but LEDs do not light, contact your technical support representative.

Troubleshooting the NPMs and Cables

Step 1 Make sure that NPMs are properly connected to the motherboard connector.

Step 2 Check the external cables.

Step 3 Check the processor or software for proper configuration.

Step 4 Check the external console connection and verify that the console baud rate is correct.

Cisco 2500 Series Startup

When you start up a Cisco 2500 series router, the following should occur:

- The System OK LED should come on and stay on as long as power is supplied
- The fans should be operating

When the system has initialized successfully, the system banner (which should look similar to the following example) should be displayed on the console screen.

```
System Bootstrap, Version (3.3), SOFTWARE
Copyright (c) 1986-1993 by cisco Systems
2500 processor with 16384 Kbytes of main memory
```

```
Unknown or ambiguous service arg - udp-small-servers
Unknown or ambiguous service arg - tcp-small-servers
Booting igs-in-l.110-9 from Flash address space
F3: 3844616+90320+228904 at 0x3000060
```

Restricted Rights Legend

```
Use, duplication, or disclosure by the Government is
subject to restrictions as set forth in subparagraph
(c) of the Commercial Computer Software - Restricted
Rights clause at FAR sec. 52.227-19 and subparagraph
(c) (1) (ii) of the Rights in Technical Data and Computer
Software clause at DFARS sec. 252.227-7013.
```

```
cisco Systems, Inc.
170 West Tasman Drive
San Jose, California 95134-1706
```

```
Cisco Internetwork Operating System Software
IOS (tm) 3000 Software (IGS-IN-L), Version 11.0(9), RELEASE SOFTWARE (fc1)
Copyright (c) 1986-1996 by cisco Systems, Inc.
Compiled Tue 11-Jun-96 01:15 by loreilly
Image text-base: 0x03020F8C, data-base: 0x00001000
```

```
cisco 2500 (68030) processor (revision A) with 16384K/2048K bytes of memory.
Processor board ID 01062462, with hardware revision 00000000
Bridging software.
X.25 software, Version 2.0, NET2, BFE and GOSIP compliant.
Basic Rate ISDN software, Version 1.0.
1 Ethernet/IEEE 802.3 interface.
2 Serial network interfaces.
1 ISDN Basic Rate interface.
32K bytes of non-volatile configuration memory.
4096K bytes of processor board System flash (Read ONLY)
```

Press RETURN to get started!

If problems occur, try to isolate the problem to a specific subsystem. The Cisco 2500 series routers have the following subsystems:

- **Power subsystem**—This subsystem includes the power supply and the wiring
- **Cooling subsystem**—This subsystem includes the fan, which should go on when power is applied
- **Network interfaces**—This subsystem includes all network interfaces, such as Ethernet, Token Ring, serial, or BRI
- **System cables**—This subsystem includes all of the external cables that connect the router to the network

Troubleshooting the Power and Cooling Subsystems

- Step 1** If the Power LED is off, make sure that the power supply is plugged into the wall receptacle and that the cable from the power supply to the router is connected.
- Step 2** If the system shuts down after being on a short time, there might have been a thermal-induced shutdown caused by a faulty fan, or the power to the system might have been lost. Ensure that the system is receiving power and that the chassis intake and exhaust vents are clear.
- Step 3** If the system does not boot up but LEDs are on, check the 12V power supply.
- Step 4** If the system partially boots but LEDs are not on, check the 5V power supply.

Troubleshooting the Network Interfaces and Cables

- Step 1** If a network interface is not recognized by the system, check the interface cable connection and the LED on the network interface.
- Step 2** If a network interface is recognized but will not initialize, check the interface cable connection.
- Step 3** If the system will not boot properly or constantly or intermittently reboots, there might be a processor or software problem. Make sure that DRAM SIMM modules are seated properly.
- Step 4** If the system boots but the console screen is frozen, check the external console connection and verify that the console baud rate is correct.
- Step 5** If the system powers on and boots with a particular interface disconnected, check the network interface connection.

Cisco 2000 Series Startup

When you start up a Cisco 2000 series router, the following should occur:

- The OK LED should come on and stay on as long as power is supplied
- The fans should be operating

When the system has initialized successfully, the system banner should be displayed on the console screen.

If there are problems during bootup, perform the steps in the following procedure.

- Step 1** Check to see if the fan is operating. If it is not, check the fan or the 12V power supply.
- Step 2** If the system shuts down after being on for a short time, check the power supply.
- Step 3** If the power supply appears operational, the router might have shutdown due to overheating. Ensure that the chassis intake and exhaust vents are clear.
- Step 4** If the system does not boot up but the System OK LED is on, check the 12V power supply to make sure it is not faulty.
- Step 5** If the system partially boots but the System OK LED is not on, check the 5V power supply to make sure it is not faulty.

Catalyst 5000 Series Startup

When you start up a Catalyst 5000 series LAN switch, the following should occur:

- The PS1 and PS2 LEDs on the supervisor engine module faceplate should be green
- The system fan assembly should be operating and the Fan LED on the supervisor engine module should come on
- The Status LED on the supervisor engine module and all interfaces should be orange until the boot is complete

When the system boot is complete the supervisor engine module should initialize the switching modules. The status LED on each switching module goes on when initialization has been completed, and the console screen displays a script and system banner similar to the following:

```

ATE0
ATS0=1
Catalyst 5000 Power Up Diagnostics
Init NVRAM Log
LED Test
ROM CHKSUM
DUAL PORT RAM r/w
RAM r/w
RAM address test
Byte/Word Enable test
RAM r/w 55aa
RAM r/w aa55
EARL test
BOOTROM Version 1.4, Dated Dec  5 1995 16:49:40
BOOT date: 00/00/00 BOOT time: 03:18:57
SIMM RAM address test
SIMM Ram r/w 55aa
SIMM Ram r/w aa55
Start to Uncompress Image ...
IP address for Catalyst not configured
BOOTP will commence after the ports are online
Ports are coming online ...
Cisco Systems Console

```

If problems occur, try to isolate the problem to a specific subsystem. The Catalyst 5000 series LAN switches have the following subsystems:

- **Power subsystem**—This subsystem includes the power supplies and power supply fans
- **Cooling subsystem**—This subsystem includes the chassis fan assembly, which should be operating when the system power is on
- **Processor and interface subsystem**—This subsystem includes the supervisor engine module (which contains the system operating software), the network interfaces, and all associated cabling

Troubleshooting the Power Subsystem

- Step 1** Check to see if the PS1 LED is on. If it is not, ensure that the power supply is connected properly and is flush with the back of the chassis. Make sure that captive installation screws are tight.
- Step 2** Check the AC source and the power cable. Connect the power cord to another power source if one is available and turn the power back on. If the LED fails to go on after you connect the power supply to a new power source, replace the power cord.
- Step 3** If the LED fails to go on when the switch is connected to a different power source with a new power cord, the power supply is probably faulty. If a second power supply is available, install it in the second power supply bay and contact a customer service representative for further instructions.
- Step 4** Repeat these steps for the second power supply if present.

Troubleshooting the Cooling Subsystem

- Step 1** Check to see if the Fan LED on the supervisor engine module is green. If it is not, check the power subsystem to see if it is operational.
- Step 2** If the Fan LED is red, the fan assembly might not be seated properly in the backplane.

To ensure that the fan assembly is seated properly, loosen the captive installation screws, remove the fan assembly and reinstall it. Tighten all captive installation screws and restart the system.
- Step 3** If the Fan LED is still red, the system has probably detected a fan assembly failure. Contact a technical support representative for assistance.

Troubleshooting the Processor and Interface Subsystem

- Step 1** Check the supervisor engine module Status and Link LEDs. These should both be green if all diagnostic and self-tests were successful and ports are operational. For more information about interpreting the supervisor engine module LEDs, refer to the user guide for your switch.
- Step 2** Check the LEDs on individual interface modules. In most cases these should be green (or should flicker green in the case of transmit and receive LEDs) if the interface is functioning correctly. For detailed information on interpreting interface module LEDs, refer to the user guide for your switch.
- Step 3** Check all cabling and connections. Replace any faulty cabling.

Catalyst 3000 Series Startup

When you start up a Catalyst 3000 series LAN switch, the following should occur:

- The Power LED should come on
- The fan should begin operating and should stay on while power is applied to the system
- On some models, the DIAG LED should come on, stay on for the duration of the system's self-test diagnostics, and then turn off

The console screen displays a script and system banner while booting, which should be similar to the following:

```
Cisco Catalyst Boot Firmware P/N 57-1327-02, Copyright 1995
- Initiating bootstrapping sequence.
- Boot image integrity check...Passed.
- Control transferred to boot process.
- Relocating main image to DRAM.....Done.
- Main image integrity check...succeeded.
- Control transferred to main process.
Cisco Catalyst 3000 System Software Version 1.1.1-B7, Copyright 1994,
1995.
System started on Fri. November 17, 1995 13:02:46
4 Megabytes System memory
2 Megabytes Network memory
- Initialization started
- File system initialized
- System temperature is within safe operating levels
- Warmboot initialization started
- Checking file system integrity
- LAN ports detected:
  - 10Base-T : 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
  - StkPort : 25
- Initializing Ports: 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 25
- Initializing system address table
- No existing diagnostic information, forcing diagnostic mode
- Starting Power Up Diagnostics test
  - UART loopback test on diagnostic port...Passed
  - UART loopback test on console port...Passed
  - RTC memory test...Passed
  - Real Time Clock test...Passed
  - CPU loopback test.....Passed
  - Ethernet Port loopback test.....Passed
  - Ethernet Port fast transmit loopback test.....Passed
  - Ethernet Port fast receive loopback test.....Passed
  - Ethernet Port cross port loopback test.....Passed
  - Ethernet Port broadcast test.....Passed

  - Catalyst Stack Port loopback test...Passed
  - Catalyst Stack Port cross port loopback test...Passed
  - Catalyst Stack Port broadcast test...Passed
  - CPU broadcast test...Passed
- Completed Power Up Diagnostics test
- System entering stand-alone mode
- Catalyst initiating bootp requests on one or more VLANs
- System initialization complete
- Enabling port: 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 25
Press RETURN key to activate console...
```

If problems occur, try to isolate the problem to a specific subsystem. The Catalyst 3000 series LAN switches have the following subsystems:

- **Power subsystem**—This subsystem includes the input power, AC power cable, and power supply
- **Cooling subsystem**—This subsystem includes the fans, which should be operating when the system power is on
- **Network interfaces and system cables subsystem**—This subsystem includes all of the network interfaces and the cables that connect the equipment to the network

Troubleshooting the Power and Cooling Subsystems

- Step 1** Check to see if the Power LED is on. If it is not on and the fans are not running, check the AC power cord and the AC receptacle the cord is plugged into.
- Make sure the cord is intact and properly attached. Swap the cord with another cord to see if the cord is faulty. Make sure the receptacle is receiving power.
- Step 2** If the Fault LED comes on after power up or after the unit has been running for a period of time, cycle the power to the unit.
- Step 3** Check to see if the fans are running and that the chassis intake vents and exhaust ports are clear.
- Step 4** Use the console connection to check if a temperature error has occurred.

Troubleshooting the Network Interfaces and System Cables Subsystem

- Step 1** If a network interface is not recognized by the system, check the interface cable and connection and the LED that corresponds to the network interface.
- Step 2** If a network interface is recognized but will not communicate properly, check the interface cable and connections.
- Step 3** If the system will not boot properly or intermittently reboots, the processor may be faulty or the hardware or software setup may be incorrect.
- Step 4** If the system boots but the console is frozen, check the external console connection and verify the console setup.

Catalyst 2900 Series Startup

When you start up a Catalyst 2900 series LAN switch, the following should occur:

- The PS LED on the supervisor engine module faceplate should come on and stay green while power is applied to the system
- The system fan assembly and Fan LED should come on and stay on while power is applied to the system
- The Status LED on the supervisor engine module and on each interface should be orange until the boot is complete

When the system boot is complete, the supervisor engine module initializes the switching modules. The status LED on each switching module goes on when initialization has been completed, and the console screen displays a script and system banner similar to the following:

```
BOOTROM Version 2.1, Dated May 22 1996 15:17:09

Boot date: 05/22/96 BOOT time: 15:17:09

Executing from RAM


Cisco Systems Console


Sending RARP request with address 00:40:0b:a0:05:b8

Sending bootp request with address 00:40:0b:a0:05:b8

Sending RARP request with address 00:40:0b:a0:05:b8

Sending bootp request with address 00:40:0b:a0:05:b8

No bootp or rarp response received

Enter password:
```

If problems occur, try to isolate the problem to a specific subsystem. The Catalyst 2900 series LAN switches have the following subsystems:

- Power subsystem—This subsystem includes the power supplies and power supply fans
- Cooling subsystem—This subsystem includes the chassis fan assembly, which should be operating when the system power is on
- Processor and interface subsystem—This subsystem includes the supervisor engine module (which contains the system operating software), the network interfaces, and all associated cabling

Troubleshooting the Power Subsystem

- Step 1** Check the Power LED. If the LED is off, ensure that the power supply cord is not damaged and that it is properly attached to the power supply and to an AC receptacle.
- Step 2** If the LED is red, the power supply has detected an anomaly or voltage outage and needs to be serviced. Contact your technical support representative for instructions.

Troubleshooting the Cooling Subsystem

- Step 1** Check to see if the Fan LED on the supervisor engine module is green. If it is not, check the power subsystem to see if it is operational.
- Step 2** If the Fan LED is red, contact a technical support representative for assistance.

Troubleshooting the Processor and Interface Subsystem

- Step 1** Check the supervisor engine module Status and Link LEDs. These should both be green if all diagnostic and self-tests were successful and ports are operational. For more information about interpreting the supervisor engine module LEDs, refer to the user guide for your switch.
- Step 2** Check the LEDs on individual interface modules. In most cases these should be green (or should flicker green in the case of transmit and receive LEDs) if the interface is functioning correctly. For detailed information on interpreting interface module LEDs, refer to the user guide for your switch.
- Step 3** Check all cabling and connections. Replace any faulty cabling.

Catalyst 1600 Token Ring Switch Startup

When you start up a Catalyst 1600 Token Ring switch, the self-test program automatically checks to see if the switch is operating correctly. The self-test begins by testing low-level hardware functions and then conducts high-level self-tests. During the high-level self-test, the LCD panel displays the following:

- The version number of the boot software, and the date and time that the software was released
- The number of each stage in the self-test (these are usually displayed too quickly for the numbers to be visible)
- A System Self Test PASSED message indicating that the self-test is complete and the Catalyst 1600 has passed the test

If the Catalyst 1600 fails the low-level test, the startup process is halted. If the Catalyst 1600 fails a high-level test, the self-test program restarts and the number of the failed test is displayed. High-level tests are repeated until the self-test is completed successfully.

If a hardware error occurs, contact your technical support representative. Be sure to note the number of the failed test and the version number of the software containing the self-test program.

LightStream 2020 Startup

When you start up a LightStream 2020 ATM switch, the blowers start running and the test and control system (TCS) applies power to the cards and initiates a series of diagnostics known as the power-on self-test (POST). POST diagnostics run automatically on each card whenever the system or the slot is powered up or when the card is reset. If a card passes POST, the green RDY LED turns on. If a card fails POST, its yellow FLT LED turns on.

If a problem occurs during system initialization, perform the following procedure first:

- Step 1** Make sure that power cords and data cables are firmly connected at both ends.
- Step 2** Make sure all cards (front and back of the chassis) are firmly seated in the midplane and screwed securely to the chassis.
- Step 3** Make sure power supplies, blowers, and disk drives are properly connected and screwed securely to the chassis.

Troubleshooting Blowers

If you are experiencing any of the following symptoms, you might need to replace the blower.

- The temperature on one or more cards is out of the recommended range.
- The system is powered on, but the blower is not turning, making noise, or exhausting air.
- Two minutes after the system is powered on, the blowers fail to reduce their speed in a room temperature environment.
- The system is powered on, but the blower's green LED is off. The LED indicates that the blower is turning at a rate of at least 1500 rotations per minute.

Troubleshooting Bulk Power Trays

In a system with one power tray, no power will be present if the power tray is faulty. There might be a problem with the power tray if cycling the system's power has no effect.

A system with two power trays can operate normally when only one is working. If you suspect a problem, use the command-line interface (CLI) command **show chassis powersupply**. If a status line for an occupied slot says anything other than Good, check the faulty power tray to see that it is properly connected. Replace the power tray if necessary.

Troubleshooting Switch Cards

If you are experiencing any of the following symptoms, you might need to replace the switch card.

- POST fails (the FLT LED stays lit and POST results indicate a problem).
- Switch card fails even when moved to the other slot. (If the card fails in one slot but operates properly in another, suspect a problem with the midplane.)
- Diagnostics that loop data through the switch card fail on two or more function cards.
- Switch card fails to come up or to select a TCS hub.
- Traffic is not passing through the system, but the line cards and NPs are operational.
- The system has data transmission problems that do not go away when you replace the card that appears to be failing, or that occur in several cards simultaneously. (Problems of this type may also indicate a faulty midplane.)
- The switch card cannot be fully inserted into its slot. This probably indicates damage to the connectors on either the card or the midplane. Inspect all the connectors and replace the card or the midplane if you find damage.

Troubleshooting NPs

If the NP fails to power up, check its access card at the back of the chassis. An NP requires an NP access card (NPAC); it cannot operate with any other kind of access card.

If the system fails to boot, it could indicate either a problem with the NP, a problem with the NP's hard disk drive, or a problem with the software on the hard drive.

If you are experiencing any of the following symptoms, you might need to replace the NP card.

- POST fails (the FLT LED stays lit and the POST results indicate a problem).
- The NP fails even when moved to the other slot. (If the card fails in one slot but operates properly in the other, suspect a problem with the midplane.)
- Hardware diagnostics fail.
- You cannot get to CLI in order to run the diagnostics.
- The card fails to load.
- The NP or its access card cannot be fully inserted into its slot. This probably indicates damage to the connectors on either the card or the midplane. Inspect all the connectors and replace the card or the midplane if you find damage.

Troubleshooting Interface Modules

The following tips will help you distinguish between problems in a line card and problems in an access card:

- Run the manufacturing diagnostics and check the information provided for the access card.
- Swap another line card of the same type. If the second card has the same problem as the first one, the access card is probably at fault. If the second card works properly, the first line card is likely to be the source of the problem.
- Faults in the line card are more common than faults in the access card. If you cannot determine which card is causing a problem, try replacing the line card.
- Use the looping tests described in the *LightStream 2020 Network Operations Guide*.

If you are having trouble bringing up an interface module, check the following:

- Make sure the access card behind the line card is compatible with the line card.
- If an FDDI module does not pass traffic, make sure the FDDI cables for each port are attached to the proper connectors.
- If you are bringing up a low-speed module, make sure the interface jumpers on the access card are set to match the physical interfaces marked on the fantails (V.35, X.21 or RS-449).
- If you are bringing up an E1 circuit emulation (CEMAC) module, make sure the interface jumpers on the access card are set properly.

If you are having signal quality problems with a physical interface on an access card, check the following:

- Make sure that cables are not too long and that your signal does not pass through too many connectors.
- Make sure that connectors are not damaged. Check optical connectors for dirt or scratches on the optical surface. For electrical connectors, check that pins are not bent, broken, or loose.

If you are experiencing any of the following symptoms, you might need to replace the line card or its access card.

- POST fails (the FLT LED stays lit and the POST indicates a problem).
- A card fails even when moved to another slot. (When you move a line card, be sure to pair it with an appropriate access card. When you move an access card, pair it with an appropriate line card.)
- Hardware diagnostics fail.

- The line card fails to load.
- The line card hangs repeatedly.
- The line card or access card cannot be fully inserted into its slot. This probably indicates damage to the connectors on either the card or the midplane. Inspect all the connectors and replace the card or the midplane if you find damage.
- Two or more ports are passing no traffic, dropping many cells, or flapping. If only one port has symptoms, there is probably a problem with the line, the external DSU/CSU if one is present, the access card, or the remote device. Use the looping tests described in the *LightStream 2020 Network Operations Guide* to help isolate the problem.

Troubleshooting Disk Assemblies

Disk assembly problems are indicated by the following symptoms:

- The node fails to boot.
- Files become corrupted.
- In a system with two NPs, the primary NP appears to fail and the backup takes over. The failed NP might pass diagnostics.
- The system fails to read or write floppy diskettes. In the case of a write failure, check the write protect switch on the diskette.

If a disk problem is indicated, check the disk assembly connector for bent or broken pins. If any pins are bent or damaged, they are the likely source of the problem. Replace the disk assembly connector.

If the connector is in good condition, the problem may be in the disk assembly itself, or in the software on the disk. If you suspect a problem with the software, you should be able to correct it by reinstalling the software as described in the *LightStream 2020 Network Operations Guide*.

Troubleshooting the Midplane

Midplane problems are indicated by the following symptoms.

- A card fails in one slot but operates normally in other slots.
- Data transmission problems do not go away when you replace the field-replacable unit (FRU) that appears to be failing, or problems occur in several FRUs simultaneously. (Problems of this type might also indicate a faulty switch card.)
- Failure of a card to fully insert into its slot. This probably indicates damage to the connectors on either the card or the midplane. Inspect all the connectors and replace the card or the midplane if you find damage.
- Electrical failure or electrical problems that do not go away when you replace the FRU that appears to be failing, or that occur in several FRUs simultaneously. Electrical problems include out-of-range voltages.

Testing and Verifying Replacement Parts

If you are replacing a part or card to remedy a suspected problem, make only one change at a time.

To test a system, start with a simple hardware configuration and add one card at a time until a failed interface appears or is isolated. Use a simple software configuration and test connectivity using a **ping** test.

If you determine that a part or card replacement is required, contact your sales or technical support representative. Specific instructions concerning part or card installation are outlined in the configuration note provided with the replacement.

For modular routers, make sure that you seat all cards correctly. Check the seating of cards if the system is not booting properly. Use the ejector levers to reseat all processor modules, then reboot.



Warning Before accessing the chassis interior and removing any cards, turn off power to the chassis. Use extreme caution around the chassis. Potentially harmful voltages are present.



Warning To prevent damage to components that are sensitive to electrostatic discharge (ESD), attach ESD protection before opening a chassis. Make certain that the power cord is connected but that power is off. ESD damage prevention guidelines are provided in the hardware installation and maintenance publication for your router.

If a part replacement appears to solve a problem, reinstall the suspect part to verify the failure. *Always* double-check a repair.

Router Fails to Boot from Flash Memory

Symptom: When booting a router from Flash memory, the boot process appears to complete, but the router does not route traffic or communicate with neighbors. EXEC commands might or might not appear to function.

Table 3-1 outlines the problems that might cause this symptom and describes solutions to those problems.

Table 3-1 Booting: Router Fails to Boot from Flash Memory

Possible Problem	Solution
Incorrect or corrupted image (EXEC does not function)	<p>Step 1 Check the configuration register using the show version EXEC command. Set the register to boot from Flash memory. For information about configuration register settings, refer to your hardware installation and maintenance documentation.</p> <p>Step 2 Power-cycle the router.</p> <p>Step 3 Within the first 60 seconds of booting, press the Break key to access the ROM monitor.</p> <p>Step 4 At the ROM monitor prompt (>), enter o/r 0x1 to set the configuration register to boot from ROM.</p> <p>Step 5 Enter i to reinitialize router, which causes the router to enter setup mode.</p> <p>Step 6 Obtain the correct system image. If necessary, contact your technical support representative to determine which image is correct.</p> <p>Step 7 After the correct image is identified, use the copy tftp flash privileged EXEC command at the router to retrieve the image.</p> <p>Step 8 Check the configuration register using the show version EXEC command. Set the register to boot from Flash memory.</p> <p>Step 9 Use the show running-config privileged EXEC command to see if the router configuration contains the boot system flash global configuration command.</p> <p>Note: Issuing the copy running-config startup-config command at this point on a Cisco 2500 series, Cisco 3000 series, Cisco 4000 series, or Cisco 7000 series will overwrite the configuration. Make sure you have a backup of your configuration file.</p> <p>Step 10 Include the boot system flash command if it is not in the configuration. Be sure to use the copy running-config startup-config command after this change.</p> <p>Step 11 Enter the reload privileged EXEC command to restart the router.</p>
Incorrect or corrupted image (EXEC functions)	<p>Step 1 Obtain the correct system image. If necessary, contact your technical support representative to determine which image is appropriate.</p> <p>Step 2 Use the copy tftp flash privileged EXEC command to retrieve the image.</p> <p>Step 3 Check the configuration register using the show version EXEC command. Set the register to boot from Flash memory. For information about configuration register settings, refer to your hardware installation and maintenance documentation.</p> <p>Step 4 Use the show running-config privileged EXEC command to determine whether the active configuration contains the boot system flash global configuration command. Use the show startup-config privileged EXEC command to determine if the boot system flash command is included in the configuration stored in NVRAM.</p> <p>Step 5 Include the boot system flash command if it is not in the configuration. Be sure to use the copy running-config startup-config privileged EXEC command to save your modification after this change.</p> <p>Step 6 Enter the reload privileged EXEC command to restart the router.</p>

Vector Error Occurs When Booting from Flash Memory

Symptom: Vector errors occur when booting a router from Flash memory.

Table 3-2 outlines the problems that might cause this symptom and describes solutions to those problems.

Table 3-2 Booting: Vector Error Occurs When Booting from Flash Memory

Possible Problem	Solution
Compressed system image	<p>Step 1 Power-cycle the router.</p> <p>Step 2 Within the first 60 seconds of booting, press the Break key to access the ROM monitor.</p> <p>Step 3 At the ROM monitor prompt (>), enter o/r to set the configuration register to boot from ROM.</p> <p>Step 4 Enter b to boot the router. The router will enter setup mode.</p> <p>Step 5 Press Ctrl-C to bypass the setup.</p> <p>Step 6 Enter the configure memory privileged EXEC command.</p> <p>Step 7 Obtain an uncompressed system image. From the router prompt, use the privileged EXEC command copy flash tftp to send the compressed image back to the TFTP server.</p> <p>Decompress the image at the TFTP server. This cannot be done at the router.</p> <p>Step 8 Use the copy tftp flash privileged EXEC command at the router to retrieve the uncompressed image.</p> <p>Step 9 Check the configuration register using the show version EXEC command. Set the router to boot from Flash memory.</p> <p>Step 10 Use the show running-config privileged EXEC command to determine whether the router configuration includes the boot system flash global configuration command in the correct order with respect to the other boot system commands.</p> <p>Note: The boot system global configuration commands are saved in the order in which they were entered. The most recent entry goes to the bottom of the list. For the recommended ordering, refer to the section “Fault-Tolerant Boot Strategies” earlier in this chapter.</p> <p>Step 11 Configure the boot system flash command if it is missing. Confirm that the order of boot system commands is correct. Use the copy running-config startup-config command to save this change.</p> <p>Step 12 Enter the reload privileged EXEC command to restart the router.</p>
Router hardware problem	Troubleshoot router hardware as discussed earlier in this chapter.

Router Partially Boots from Flash and Displays Boot Prompt

Symptom: When booting a Cisco 2000, Cisco 2500, Cisco 3000, or Cisco 4000 series router from Flash memory, the boot process halts and the console displays the boot prompt [router(boot)>]. In addition, the router will not route, although EXEC commands might appear to be operational.

Table 3-3 outlines the problems that might cause this symptom and describes solutions to those problems.

Table 3-3 Booting: Router Partially Boots from Flash and Displays Boot Prompt

Possible Problem	Solution
No system image in Flash memory	<p>Step 1 Use the show flash EXEC command to determine whether an image exists in Flash memory.</p> <p>Step 2 If no image exists, use the copy tftp flash privileged EXEC command to copy the system image from your TFTP server to the router's Flash memory.</p> <p>Step 3 Enter the reload privileged EXEC command to reboot the router.</p>
Missing boot system flash global configuration command	<p>Step 1 Use the show running-config privileged EXEC command to determine whether the configuration includes a boot system flash global configuration command entry. Use the show startup-config privileged EXEC command to determine if the boot system flash command is included in the configuration stored in NVRAM.</p> <p>Step 2 Check the order of the boot system commands. For the recommended ordering, refer to the section "Fault-Tolerant Boot Strategies" earlier in this chapter.</p> <p>Step 3 Add the boot system flash command or reorder the boot system commands if necessary.</p> <p>Step 4 Save the configuration change to NVRAM using the copy running-config startup-config privileged EXEC command.</p>
Misconfigured configuration register	Use the show version EXEC command to check the configuration register setting. Make sure it is set to boot from Flash memory. Refer to your hardware installation and maintenance publication for details regarding configuration register settings.

Router Cannot Netboot from TFTP Server

Symptom: Router cannot boot from a TFTP server. The router tries to obtain its system image over the network but fails.

The following output is an example of a failed netboot session:

```
Booting gs3-bfx.....[failed]
```

Table 3-4 outlines the problems that might cause this symptom and describes solutions to those problems.

Note More specific symptoms related to TFTP servers and netbooting are described later in this chapter.

Table 3-4 Booting: Router Cannot Netboot from TFTP Server

Possible Problem	Solution
Network is disconnected or isolated	<p>Step 1 Boot the router from ROM or Flash memory if possible.</p> <p>Step 2 Use the ping EXEC command to send a message to the broadcast address (255.255.255.255).</p> <p>Step 3 If there is no response from the server, use the show arp EXEC command to look for an entry in the ARP table that is associated with the server.</p> <p>Step 4 Use the show ip route EXEC command to view the IP routing table. Look for an entry in the table for the network or subnet of the server.</p> <p>If a path to a boot server exists, a disconnected network is not the problem. If no path exists, make sure that a path is available before again attempting to netboot.</p>
TFTP server is down	<p>Step 1 Check the TFTP server to determine whether it is up and running. You can do this by attempting to make a TFTP connection from the boot server to itself. The connection will be successful if the TFTP server is running.</p> <p>Step 2 If the TFTP server is not running, initialize it. The initialization process will vary depending on the type of boot server.</p> <p>For a BSD UNIX server, check the <i>/etc/inetd.conf</i> file. If the TFTP server is not included in this file, add the appropriate line and cause inetd to reload its configuration.</p>
Router image in wrong directory	<p>Step 1 Look at the server configuration file to see if it points to the directory in which the router image is located.</p> <p>Step 2 Move the router image to the correct directory if necessary.</p> <p>Step 3 Make sure the <i>/tftpboot</i> directory is reachable over the network.</p>
Router system image file permissions are incorrect	<p>Step 1 Check the permissions of the system image file.</p> <p>Step 2 If necessary, change the permissions for the file. On a UNIX boot server, set the permissions for the file to owner read/write, group read, and global read (the UNIX command for setting these permissions is chmod 644 filename).</p>
Bad protocol address	<p>Step 1 Check the server configuration file to make sure the IP address of the host is correct.</p> <p>Step 2 Change the configuration if it is incorrect.</p>

Possible Problem	Solution
Missing or misconfigured default gateway specification	<p>Step 1 Use the show running-config privileged EXEC command to view the router configuration. Check for the ip default-gateway global configuration command, which defines a default gateway.</p> <p>Step 2 If the command is missing, add it to the configuration. If the command is present, make sure it specifies the correct IP address.</p>
Misconfigured boot system command	<p>Step 1 Use the show running-config privileged EXEC command to view the router configuration. Check the boot server address (IP address of a TFTP server or MAC address of a MOP server) that is configured on the router.</p> <p>Step 2 If the address is specified incorrectly, specify the correct boot server address using the boot system global configuration command.</p>
Wrong filename is specified	<p>Step 1 Use the show running-config privileged EXEC command to view the router configuration. Check the boot filename that is configured on the router.</p> <p>Step 2 Make sure the filename is specified correctly. Change the filename if necessary. Check the host documentation for details about setting the name of the system image on the TFTP server.</p> <p>Step 3 Some versions of the ROM are case sensitive. Try changing the case of the filename. Contact your technical support representative for more information.</p>
Incorrect configuration register setting	<p>To netboot from a server, you must set the configuration register properly. The specific configuration for netbooting depends on the platform that is being booted.</p> <p>Step 1 Check the configuration register setting for your system.</p> <p>Step 2 Determine whether you want to manually or automatically netboot from a TFTP server.</p> <p>To manually netboot, the configuration register must be set to 0x0; otherwise, you will be netbooting using the default system image name or the image specified by the boot system global configuration command.</p> <p>Refer to the Cisco IOS configuration guides and command references and your hardware installation and maintenance publications for more details about setting the configuration register.</p>

Symptom: A router cannot boot properly when booting from another router acting as a TFTP server.

Timeouts and Out-of-Order Packets Prevent Netbooting

Symptom: Timeouts or out-of-order packets prevent successful netbooting. The number of timeouts and out-of-order packets indicated on the router's console display might vary.

The following example shows a netbooting session that contains excessive timeouts and out-of-order packets:

```
Booting gs3-bfx from 131.108.1.123: !O.O!.O..O!!!OOO.O!!..O.O.....
```

The client router might boot in this situation. However, when excessive timeouts and out-of-order packets occur, there is probably a network problem, and netbooting (as well as network service availability) might be inconsistent.

Table 3-6 outlines the problems that might cause this symptom and describes solutions to those problems.

Table 3-6 Booting: Timeouts and Out-of-Order Packets Prevent Netbooting

Possible Problem	Solution
Link is saturated	<p>Step 1 Boot the router from ROM and ping the TFTP server. Determine whether timeouts and out-of-order packets appear.</p> <p>Step 2 Check local network concentrators for excessive collisions on the same network. If there are excessive collisions, reorganizing your network topology might help reduce collisions.</p> <p>Step 3 Use the show interfaces EXEC command on routers in the path or place a network analyzer between the router and server. Look for dropped packets and output errors.</p> <p>Step 4 If approximately 15 percent or more of the traffic is being dropped, or if any output errors occur, congestion might be the problem.</p> <p>Step 5 Wait until the traffic subsides before attempting to netboot the router. If the problem is chronic, increase bandwidth or move the server closer to the router being booted.</p>
Link is down	<p>Step 1 Check the continuity of the path from the booting router to the boot server using ping or trace EXEC commands.</p> <p>Step 2 If a break is found, restore the link and attempt to netboot again.</p>

Invalid Routes Prevent Netbooting

Symptom: Invalid routes prevent successful netbooting. If the router is sending packets over an invalid path, a message similar to one of the following is displayed on the console:

```
Booting gs3-bfx!0000.....[timed out]

Booting gs3-bfx!.0.0.0.0.....[timed out]

Booting gs3-bfx!!!!!!!!!!!!0000000000.....[timed out]
```

In some cases, there might be an initial response from a server but the netboot sequence still fails. The boot message would be similar to the following:

```
Booting gs3-bfx!.....[failed]
```

Table 3-7 outlines the problems that might cause this symptom and describes solutions to those problems.

Table 3-7 Booting: Invalid Routes Prevent Netbooting

Possible Problem	Solution
Bad routing paths on neighbor routers	Step 1 Verify that neighbor routers can ping the server.
	Step 2 Use the trace EXEC command to determine the path to the server.
	Step 3 Use the show arp privileged EXEC command to examine the ARP tables or the show ip route privileged EXEC command to view the IP routing table. Verify that the server is listed and that the routing table entries are appropriate.
	Step 4 Use the clear arp-cache and clear ip-route privileged EXEC commands to force the router to repopulate its ARP and routing tables.
	Step 5 Try to netboot the router again.
Problems caused by multiple paths	Step 1 Shut down all extra interfaces except the one over which you intend to netboot the router.
	Step 2 Use the no ip proxy-arp interface configuration command on all neighboring routers to disable their ability to provide proxy ARP responses. Make this change with care because it can cause problems for other network traffic. If you do not want to disable proxy ARP, boot the router from ROM and configure the ip default-gateway global configuration command.
	Step 3 Try to netboot the router again.

Client ARP Requests Time Out during Netboot

Symptom: Client ARP requests time out during a netboot. If the router does not receive an ARP response, a message similar to the following is displayed on the console:

```
Booting gs3-bfx.....[timed out]
```

Table 3-8 outlines the problems that might cause this symptom and describes solutions to those problems.

Table 3-8 Booting: Client ARP Requests Time Out during Netboot

Possible Problem	Solution
Intermediate routers have ARP filtering enabled	<p>Step 1 Boot the router from ROM.</p> <p>Step 2 Make sure you can ping the server from the router.</p> <p>Step 3 Use the copy running-config tftp privileged EXEC command to test TFTP connectivity to the server.</p> <p>Step 4 If the preceding steps are successful, check the configuration at the intermediate router using the show arp EXEC command.</p> <p>Step 5 Enable the debug arp privileged EXEC command to determine whether neighbor proxy ARP responses are being generated.</p> <p>Step 6 If the neighbor is not sending proxy ARP responses and its configuration contains the no ip proxy-arp interface configuration command, disable ARP filtering by removing the entry.</p> <p>Note that proxy ARP is enabled by default.</p> <p>Step 7 If you need to have a no ip proxy-arp entry in the neighbor router configurations, use the ip default-gateway global configuration command on the router to specify a default gateway.</p>
Missing or misconfigured IP helper address on intermediate router	<p>Step 1 Check the configurations of all routers in the path. Make sure that all intermediate routers have an IP helper address specified that points to the TFTP server.</p> <p>Step 2 Include helper addresses as required using the ip helper-address interface configuration command.</p> <p>If you are unicasting to your server, you do not need to use the IP helper address, but if you are broadcasting to 255.255.255.255 (by omitting the IP address of the server), add the ip helper-address command on the <i>neighboring</i> router interface used in the netbooting broadcast.</p>

Undefined Load Module Error When Netbooting

Symptom: An undefined load module error occurs during a netboot. The console display indicates an “undefined load module” error, and the router is unable to boot.

Table 3-9 outlines the problems that might cause this symptom and describes solutions to those problems.

Table 3-9 Booting: Undefined Load Module Error When Netbooting

Possible Problem	Solution
Filename mismatch	<p>Step 1 If you are booting manually, refer to the user guide for your router to see the proper command line format.</p> <p>Step 2 Check the router configuration file. Compare the filename specified in the boot system filename [address] global configuration command entry with the actual router image filename. Make sure they match.</p> <p>Step 3 If the filenames differ, change the name in the configuration file.</p> <p>Remember to use the router image filename in the boot system global configuration command specification and the configuration filename with the boot host and boot network global configuration commands.</p>

Router Hangs after ROM Monitor Initializes

Symptom: When booting a Cisco 7000 series, AGS+, AGS, ASM-CS, MGS, IGS, or CGS router from ROM, the system hangs after the ROM monitor initializes.

Table 3-10 outlines the problems that might cause this symptom and describes solutions to those problems.

Table 3-10 Booting: Router Hangs after ROM Monitor Initializes

Possible Problem	Solution
Incorrect EPROM size setting	<p>Step 1 Power off the system.</p> <p>Step 2 Inspect EPROM size jumpers. Refer to the hardware installation and maintenance publication for your router to determine the proper setting.</p> <p>Step 3 Move jumpers as required.</p>
Configuration register is not set correctly	<p>Step 1 Check your configuration settings (boot ROM jumpers and software configuration). If no jumper is set at bit 0, and no other boot field is defined, you must reconfigure your system so that it can boot properly.</p> <p>Step 2 To enable your router to boot properly, do one of the following:</p> <ul style="list-style-type: none"> • Configure the software configuration register of the router using the config-register value global configuration command. (This applies to the IGS, Cisco 2500, Cisco 3000, and Cisco 7000 platforms running Cisco IOS Release 10.0 or later in the EPROM.) • Set the boot ROM jumper to permit booting. • Include the correct boot system global configuration commands to boot the system. • Set bit 0 to a value of 1 to force booting from ROM. <p>Refer to the Cisco IOS configuration guides and command references, and your hardware installation and maintenance publications, for more information about configuring your router for the various booting options.</p>

Router Is Stuck in ROM Monitor Mode

Symptom: Router is stuck in ROM monitor mode. When booting a router from ROM, the system boots into ROM monitor mode but does not boot the complete system image.

Table 3-11 outlines the problems that might cause this symptom and describes solutions to those problems.

Table 3-11 Booting: Router Is Stuck in ROM Monitor Mode

Possible Problem	Solution
Incorrect configuration register setting	<p>Step 1 At the ROM monitor prompt (>), enter b to boot the system.</p> <p>Step 2 If a configuration exists in NVRAM, the system will display the vacant message. Press the Return key to continue.</p> <p>If a configuration does not exist in NVRAM, the setup menu appears. Skip the setup process.</p> <p>Step 3 Use the show version EXEC command to determine the configuration register setting.</p> <p>Step 4 Look for an invalid configuration register setting. The default is 0x101, which disables the Break key and forces the router to boot from ROM. A typical “bad” setting has a zero in the least significant bit (for example 0x100).</p> <p>For details about setting the configuration register, refer to your hardware installation and maintenance publication.</p>
Break key pressed during boot process	At the ROM monitor prompt, enter c to allow the router to continue booting.
Console cable inserted or removed during boot process, or console power-cycled during boot process	<p>Step 1 Press the Return key and wait for the ROM monitor prompt (>).</p> <p>Step 2 If the ROM monitor prompt appears, enter c at the prompt to continue the booting process.</p>

Scrambled Output When Booting from ROM

Symptom: When booting from ROM, the router displays indecipherable textual output on the console.

Table 3-12 outlines the problems that might cause this symptom and describes solutions to those problems.

Table 3-12 Booting: Scrambled Output When Booting from ROM

Possible Problem	Solution
Wrong terminal speed setting	Step 1 Use the monitor setup menu to check the terminal line speed setting for the monitor. Step 2 Check the terminal speed configured on the router as specified in the configuration register setting (default is 9600 baud, 8 databits, 2 stop bits, and no parity). Step 3 If the terminal speed of the monitor and the router do not match, modify as necessary. Refer to your hardware installation and maintenance documentation for details about setting up the monitor.
Router hardware problem	Check all hardware for damage, including cabling (broken wire), adapters (loose pin), router ports, and so forth. For more information, refer to the hardware troubleshooting information discussed earlier in this chapter.

Local Timeouts Occur When Booting from ROM

Symptom: “Local timeout” error messages are generated when booting from ROM. The router is unable to complete its boot process and will not start the ROM monitor.

Table 3-13 outlines the problems that might cause this symptom and describes solutions to those problems.

Table 3-13 Booting: Local Timeouts Occur When Booting from ROM

Possible Problem	Solution
EPROM problem	Generally, this problem occurs only if you have just replaced your system EPROMs Step 1 Power off the system. Step 2 Inspect each EPROM. Make sure each EPROM is correctly positioned in the socket (with notches properly aligned) in the correct socket. Step 3 If a pin is bent, straighten it carefully. Reinstall the EPROM and power on the system. If a pin breaks off, the EPROM must be replaced. Step 4 If an EPROM has been installed backward and power has been applied to it, the EPROM has been damaged and must be replaced. Step 5 If local timeouts persist, contact your technical support representative.

Unresponsive Terminal Connection to Unconfigured Access Server

Symptom: A terminal connected to an unconfigured access server is unresponsive. The terminal, attached to the console port of an unconfigured Cisco access server, displays bootup banners and begins the Setup routine, but the user cannot input commands from the terminal keyboard.

Table 3-14 outlines the problems that might cause this symptom and describes solutions to those problems.

Table 3-14 Booting: Unresponsive Terminal Connection to Unconfigured Access Server

Possible Problem	Solution
Flow control configured on the terminal conflicts with the EIA/TIA-232 control signals supported by the access server console port (RJ-45 to DB-25)	<p>Step 1 Check if flow control is configured on your terminal.</p> <p>Step 2 Disable all flow control on the terminal. With flow control enabled, the terminal will wait indefinitely for a CTS¹ signal because the RJ-45 console port on the access server does not assert CTS.</p> <p>For information on how to check for and disable flow control on your specific terminal, consult the documentation provided by your terminal manufacturer.</p> <p>Step 3 Alternatively, you can strap CTS high by providing the proper voltage on the CTS signal lead to make the signal active. Find an unused signal that is known to be active and “strap,” or short, CTS to it. The terminal sees CTS being asserted (indicating that the access server is ready to receive data) and allows input to be entered.</p> <p>Step 4 On an already configured access server, another solution is to connect your terminal to the auxiliary port of the access server. The auxiliary port, unlike the console port, asserts CTS and the terminal will therefore allow input. However, on a new access server with no configuration, this is <i>not</i> an alternative, because the bootup banners and Setup routine are seen only on the console port.</p>
Hardware problem	<p>Step 1 Check all hardware for damage, including cabling (broken wires), adapters (loose pins), access server ports, and the terminal itself.</p> <p>Step 2 Replace any hardware that is damaged or excessively worn. For more information, refer to the hardware troubleshooting information earlier in this chapter.</p>

1. CTS=Clear to Send

