



Doc. No. 78-3052-01

1-Port and 2-Port ISDN-PRI Network Module Configuration Note

Product Numbers:

NM-1CT1, NM-1CT1-CSU, NM-2CT1, NM-2CT1-CSU, NM-1CE1-B, NM-2CE1-B, NM-1CE1-U, NM-2CE1-U

CPANM-1CT1, CPANM-1CT1-CSU, CPANM-2CT1, CPANM-2CT1-CSU, CPANM-1CE1-B, CPANM-2CE1-B, CPANM-1CE1-U, CPANM-2CE1-U

This document provides information about the following network modules for the Cisco 3600 series of modular access routers:

- 1-port channelized T1/ISDN-PRI network module, Cisco product number NM-1CT1 or CPANM-1CT1. (See Figure 1.) This module will also be referred to as the 1-port CT1/PRI network module.
- 2-port channelized T1/ISDN-PRI network module, Cisco product number NM-2CT1 or CPANM-2CT1. (See Figure 2.) This module will also be referred to as the 2-port CT1/PRI network module.
- 1-port channelized T1/ISDN-PRI with CSU network module, Cisco product number NM-1CT1-CSU or CPANM-1CT1-CSU. (See Figure 3.) This module will also be referred to as the 1-port CT1/PRI-CSU network module.
- 2-port channelized T1/ISDN-PRI with CSU network module, Cisco product number NM-2CT1-CSU or CPANM-2CT1-CSU. (See Figure 4.) This module will also be referred to as the 2-port CT1/PRI-CSU network module.
- 1-port channelized E1/ISDN-PRI balanced (120-ohm) network module, Cisco product number NM-1CE1B or CPANM-1CE1B. (See Figure 5.) This module will also be referred to as the 1-port CE1/PRI-B network module.

Corporate Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA

Copyright © 1996
Cisco Systems, Inc.
All rights reserved.

- 2-port channelized E1/ISDN-PRI balanced (120-ohm) network module, Cisco product number NM-2CE1B or CPANM-2CE1B. (See Figure 6.) This module will also be referred to as the 2-port CE1/PRI-B network module.
- 1-port channelized E1/ISDN-PRI unbalanced (75-ohm) network module, Cisco product number NM-1CE1U or CPANM-1CE1U. (See Figure 5.) This module will also be referred to as the 1-port CE1/PRI-U network module.
- 2-port channelized E1/ISDN-PRI unbalanced (75-ohm) network module, Cisco product number NM-2CE1U or CPANM-2CE1U. (See Figure 6.) This module will also be referred to as the 2-port CE1/PRI-U network module.

Unless specifically identified, references to PRI modules in this configuration note include all these network modules.

Figure 1 1-Port Channelized T1/ISDN-PRI Network Module




Figure 2 2-Port Channelized T1/ISDN-PRI Network Module




Figure 3 1-Port Channelized T1/ISDN-PRI with CSU Network Module




Figure 4 2-Port Channelized T1/ISDN-PRI with CSU Network Module




Figure 5 1-Port Channelized E1/ISDN-PRI Network Module (Balanced or Unbalanced)





Figure 6 2-Port Channelized E1/ISDN-PRI Network Module (Balanced or Unbalanced)



Use this document in conjunction with your router installation and configuration guide and the *Regulatory Compliance and Safety Information* publication. If you have questions or need help, refer to the section “Obtaining Service and Support” later in this document for further information.

This document contains the following sections:

- Safety Recommendations, page 4
- Required Tools and Equipment, page 6
- Installing PRI Network Modules in a Chassis Slot, page 7
- Connecting the PRI Module to the Network, page 8
- PRI Module Pinouts, page 11

- PRI Module LEDs, page 14
- Configuring the PRI Interfaces, page 17
- Obtaining Service and Support, page 22
- Cisco Connection Online, page 22



Warning Only trained and qualified personnel should be allowed to install or replace this equipment. (To see translated versions of this warning, refer to the *Regulatory Compliance and Safety Information* document that accompanied the router.)



Warning Before working on a chassis or working near power supplies, unplug the power cord on AC units; disconnect the power at the circuit breaker on DC units. (To see translated versions of this warning, refer to the *Regulatory Compliance and Safety Information* document that accompanied the router.)



Warning Ultimate disposal of this product should be handled according to all national laws and regulations. (To see translated versions of this warning, refer to the *Regulatory Compliance and Safety Information* document that accompanied the router.)



Caution To avoid damaging electrostatic discharge (ESD)-sensitive components, ensure that you have discharged all static electricity from your body before opening the chassis. Before performing procedures described in this document, review the next section, “Safety Recommendations.”

Safety Recommendations

Follow these guidelines to ensure general safety:

- Keep the chassis area clear and dust-free during and after installation.
- Put the removed chassis cover in a safe place.
- Keep tools away from walk areas where you or others could fall over them.
- Do not wear loose clothing that could get caught in the chassis. Fasten your tie or scarf and roll up your sleeves.
- Wear safety glasses when working under any conditions that might be hazardous to your eyes.
- Do not perform any action that creates a potential hazard to people or makes the equipment unsafe.



Warning The ISDN connection is regarded as a source of voltage that should be inaccessible to user contact. Do not attempt to tamper with or open any public telephone operator (PTO)-provided equipment or connection hardware. Any hardwired connection (other than by a nonremovable, connect-one-time-only plug) must be made only by PTO staff or suitably trained engineers. (To see translated versions of this warning, refer to the *Regulatory Compliance and Safety Information* document that accompanied the router.)



Warning Network hazardous voltages are present in the BRI cable. If you detach the BRI cable, detach the end away from the router first to avoid possible electric shock. Network hazardous voltages also are present on the system card in the area of the BRI port (RJ-45 connector), regardless of when power is turned off. (To see translated versions of this warning, refer to the *Regulatory Compliance and Safety Information* document that accompanied the router.)



Warning The Ethernet 10BaseT, Token Ring, serial, console, and auxiliary ports contain safety extra-low voltage (SELV) circuits. BRI circuits are treated like telephone-network voltage (TNV) circuits. Avoid connecting SELV circuits to TNV circuits. (To see translated versions of this warning, refer to the *Regulatory Compliance and Safety Information* document that accompanied the router.)

Safety with Electricity



Warning Before working on equipment that is connected to power lines, remove jewelry (including rings, necklaces, and watches). Metal objects will heat up when connected to power and ground and can cause serious burns or weld the metal object to the terminals. (To see translated versions of this warning, refer to the *Regulatory Compliance and Safety Information* document that accompanied the router.)

Follow these guidelines when working on equipment powered by electricity:

- Locate the emergency power-OFF switch in the room in which you are working. Then, if an electrical accident occurs, you can quickly shut the power OFF.
- Before working on the router, turn OFF the power and unplug the power cord.
- Disconnect all power before doing the following:
 - Installing or removing a router chassis
 - Working near power supplies
 - Performing a software upgrade
- Do not work alone if potentially hazardous conditions exist.



Warning Before opening the chassis, disconnect the telephone-network cables to avoid contact with telephone-network voltages. (To see translated versions of this warning, refer to the *Regulatory Compliance and Safety Information* document that accompanied the router.)



Warning Do not work on the system or connect or disconnect cables during periods of lightning activity. (To see translated versions of this warning, refer to the *Regulatory Compliance and Safety Information* document that accompanied the router.)

- Never assume that power is disconnected from a circuit. Always check.



Warning Do not touch the power supply when the power cord is connected. For systems with a power switch, line voltages are present within the power supply even when the power switch is OFF and the power cord is connected. For systems without a power switch, line voltages are present within the power supply when the power cord is connected. (To see translated versions of this warning, refer to the *Regulatory Compliance and Safety Information* document that accompanied the router.)

- Look carefully for possible hazards in your work area, such as moist floors, ungrounded power extension cables, and missing safety grounds.
- If an electrical accident occurs, proceed as follows:
 - Use caution; do not become a victim yourself.
 - Turn OFF power to the router.
 - If possible, send another person to get medical aid. Otherwise, determine the condition of the victim and then call for help.
 - Determine if the person needs rescue breathing or external cardiac compressions; then take appropriate action.

Preventing Electrostatic Discharge Damage

Electrostatic discharge (ESD) can damage equipment and impair electrical circuitry. It occurs when electronic printed circuit cards are improperly handled and can result in complete or intermittent failures. Always follow ESD prevention procedures when removing and replacing cards. Ensure that the router chassis is electrically connected to earth ground. Wear an ESD-preventive wrist strap, ensuring that it makes good skin contact. Connect the clip to an unpainted surface of the chassis frame to safely channel unwanted ESD voltages to ground. To properly guard against ESD damage and shocks, the wrist strap and cord must operate effectively. If no wrist strap is available, ground yourself by touching the metal part of the chassis.



Caution For safety, periodically check the resistance value of the antistatic strap, which should be between 1 and 10 megohms (Mohm).

Required Tools and Equipment

You need the following tools and equipment to install a network module in a Cisco 3600 series chassis slot:

- Network module
- Number 1 Phillips screwdriver or small flat-blade screwdriver
- ESD-preventive wrist strap

Installing PRI Network Modules in a Chassis Slot



Caution Network modules do not support online insertion and removal (hot swap). To avoid damaging the module, before you insert a network module into a chassis slot, you must turn OFF electrical power and disconnect network cables.

The following instructions apply only to installing network modules in a chassis slot. To install a WAN interface card in a network module, see the configuration note for the WAN interface card.

You can install network modules in the chassis either before or after mounting the router, whichever is more convenient.

Note Do not install a PRI network module in the same chassis as an ISDN Basic Rate Interface (BRI) network module or a BRI WAN interface card. This configuration is not supported.

Follow this procedure to install a network module:

Step 1 Turn OFF electrical power to the router. However, to channel ESD voltages to ground, do not unplug the power cable. Remove all network interface cables, including telephone cables, from the rear panel.

The following warning applies to routers that use a DC power supply:



Warning Before performing any of the following procedures, ensure that power is removed from the DC circuit. To ensure that all power is OFF, locate the circuit breaker on the panel board that services the DC circuit, switch the circuit breaker to the OFF position, and tape the switch handle of the circuit breaker in the OFF position. (To see translated versions of this warning, refer to the *Regulatory Compliance and Safety Information* document that accompanied the router.)

Step 2 Using either a number 1 Phillips screwdriver or a small flat-blade screwdriver, remove the blank filler panel from the chassis slot where you plan to install the module. Save the blank panel for future use.

Step 3 Align the network module with the guides in the chassis and slide it gently into the slot.

Step 4 Push the module into place until you feel its edge connector mate securely with the connector on the motherboard.

Step 5 Fasten the module's captive mounting screws into the holes in the chassis, using the Phillips or flat-blade screwdriver.

Step 6 If the router was previously running, reinstall the network interface cables and turn ON power to the router.

The following warning applies to routers that use a DC power supply:




Warning After wiring the DC power supply, remove the tape from the circuit breaker switch handle and reinstate power by moving the handle of the circuit breaker to the ON position. (To see translated versions of this warning, refer to the *Regulatory Compliance and Safety Information* document that accompanied the router.)

Blank Network Module Panels

If the router is configured with fewer than four network modules, make sure that blank panels fill the open chassis slots to provide proper airflow. (See Figure 7.)

Figure 7 Blank Network Module Panel



Connecting the PRI Module to the Network

This section explains how to connect a PRI network module to a WAN.

CT1/PRI Modules

To connect a CT1/PRI module, use a DB-15-to-DB-15 T1 serial cable to connect the CT1/PRI port to a T1 CSU. (See Figure 8.)

Figure 8 Connecting a CT1/PRI Module to a T1 CSU





Figure 13 Connecting a CE1/PRI-U Module to an E1 CSU (DB-15-to-BNC Connectors)



PRI Module Pinouts

This section describes PRI network module cables and lists their pinouts.

CT1/PRI Pinouts

Two standard T1 serial cables are available for the CT1/PRI network module, straight-through and null-modem. A straight-through cable connects the router to an external channel service unit (CSU). Null-modem cables are used for back-to-back operation and testing.

T1 interface cables have two male DB-15 connectors (one at each end) to connect the CT1/PRI module with the external T1 CSU. Figure 14 shows the cable and connectors. Table 1 lists the pinout for the straight-through T1 cable, and Table 2 lists the pinout for the null-modem T1 cable.

Figure 14 T1 Interface Cable




Table 1 Straight-Through T1 Cable Pinout

DB-15 Connector		DB-15 Connector	
Signal	Pin	Pin	Signal
Transmit Tip	1	1	Transmit Tip
Transmit Ring	9	9	Transmit Ring
Receive Tip	3	3	Receive Tip
Receive Ring	11	11	Receive Ring

Table 2 Null-Modem T1 Cable Pinout

DB-15 Connector		DB-15 Connector	
Signal	Pin	Pin	Signal
Transmit Tip	1	3	Receive Tip
Receive Tip	3	1	Transmit Tip
Transmit Ring	9	11	Receive Ring
Receive Ring	11	9	Transmit Ring

CT1/PRI-CSU Pinout

Table 3 lists the pinout for the CT1/PRI-CSU network module.

Table 3 CT1/PRI-CSU Network Module (RJ-48C Port) Pinout

RJ-48C Pin	Signal
1	Receive Ring
2	Receive Tip
4	Ring
5	Tip

CE1/PRI Pinouts

Cisco Systems offers three serial cables for 120-ohm balanced CE1/PRI-B network modules and one serial cable for 75-ohm unbalanced CE1/PRI-U network modules. All four E1 cables have a DB-15 connector at the router end. Cables for CE1/PRI-B modules have either DB-15, Twinax, or RJ-45 connectors at the network end. (See Figure 15, Figure 16, and Figure 17.) The cable for CE1/PRI-U modules has a BNC connector at the network end. (See Figure 18.)

Figure 15 E1 Interface Cable for 120-Ohm Balanced Connections (DB-15 Connector)




Figure 16 E1 Interface Cable for 120-Ohm Balanced Connections (Twinax Connectors)




Figure 17 E1 Interface Cable for 120-Ohm Balanced Connections (RJ-45 Connector)




Figure 18 E1 Interface Cable for 75-Ohm Unbalanced Connections (BNC Connectors)




Table 4 lists pinouts for the CE1/PRI cables.

Table 4 CE1/PRI Network Module Cable Pinouts

CE1/PRI End		Network End						
DB-15		BNC	DB-15		Twinax		RJ-45	
Pin	Signal ¹	Signal	Pin	Signal	Pin	Signal	Pin	Signal
9	Tx Tip	Tx Tip	1	Tx Tip	Tx-1	Tx Tip	4	Tx Tip
2	Tx Ring	Tx Shield	9	Tx Ring	Tx-2	Tx Ring	5	Tx Ring
10	Tx Shield	–	2	Tx Shield	Shield	Tx Shield	6	Tx Shield
8	Rx Tip	Rx Tip	3	Rx Tip	Rx-1	Rx Tip	1	Rx Tip
15	Rx Ring	Rx Shield	11	Rx Ring	Rx-2	Rx Ring	2	Rx Ring
7	Rx Shield	–	4	Rx Shield	Shield	Rx Shield	3	Rx Shield

1. Tx = transmit. Rx = receive.

PRI Module LEDs

All network modules have an enable LED. This LED indicates that the module has passed its self-tests and is available to the router.

All PRI modules display four additional LEDs for each port. These LEDs are described in Table 5.

Table 5 ISDN-PRI Network Module LEDs

LED	Meaning
REMOTE ALARM	Local alarm at remote end of connection
LOCAL ALARM	Loss of signal, loss of frame, or unavailability because of excessive errors
LOOPBACK	Controller local loopback
CARRIER DETECT	Carrier received on telco link

The following sections illustrate these LEDs.

CT1/PRI Module LEDs

Figure 19 and Figure 20 show CT1/PRI network module LEDs.

Figure 19 1-Port CT1/PRI Network Module LEDs





Figure 20 2-Port CT1/PRI Network Module LEDs



CT1/PRI-CSU Module LEDs

Figure 21 and Figure 22 show CT1/PRI-CSU module LEDs.

Figure 21 1-Port CT1/PRI-CSU Network Module LEDs





Figure 22 2-Port CT1/PRI-CSU Network Module LEDs



CE1/PRI Module LEDs

Figure 23 and Figure 24 show CE1/PRI module LEDs. The same LEDs are used for balanced (120-ohm) and unbalanced (75-ohm) E1 interfaces.

Figure 23 1-Port CE1/PRI Network Module LEDs





Figure 24 2-Port CE1/PRI Network Module LEDs



Configuring the PRI Interfaces

Whenever you install a new interface, or if you want to change the configuration of an existing interface, you must configure the interface. If you replace a module that was already configured, the router recognizes it and brings up the interface in the existing configuration.

Before you configure an interface, have the following information available:

- T1 or E1 information—for example, clock source, line code, and framing type
- Channel-group information and time-slot mapping
- Protocols you plan to route on the new interface
- IP addresses, subnet masks, network numbers, zones, or other information related to the routing protocol



Timesaver Obtain this information from your system administrator or network plan before you begin router configuration.

To configure a PRI interface, you must use configuration mode (manual configuration). In this mode, you enter Cisco Internetwork Operating System (Cisco IOS) commands at the router prompt.

The following sections explain how to configure PRI interfaces. Before you begin, disconnect all WAN cables from the router to keep it from trying to run the AutoInstall process. The router tries to run AutoInstall whenever you power it ON if there is a WAN connection on both ends and the router does not have a valid configuration file stored in nonvolatile random-access memory (NVRAM) (for instance, when you add a new interface). It can take several minutes for the router to determine that AutoInstall is not connected to a remote Transmission Control Protocol/Internet Protocol (TCP/IP) host.

If you have questions or need help, refer to the section “Obtaining Service and Support” later in this document for further information.

Configuring T1 Interfaces

The following procedure can be used to configure a new CT1/PRI or CT1/PRI-CSU module or to change the configuration of an existing module.

To enter configuration mode, follow this procedure:

- Step 1** Connect a console to the router. If you need instructions for connecting a console, refer to the installation chapter of your router installation and configuration guide. Power up the router.
- Step 2** If the current configuration is no longer valid, after about a minute you see the following prompt:

```
Would you like to enter the initial dialog? [yes]:
```

Answer **no**. You now enter the normal operating mode of the router.

Note If the current configuration is valid, you enter the normal operating mode automatically.

- Step 3** After a few seconds you see the user EXEC prompt (Router>). Type **enable** and the password to enter enable mode:

```
Router> enable
Password:
```

Configuration changes can be made only in enable mode. The prompt changes to the privileged EXEC (enable) prompt (Router#):

```
Router#
```

- Step 4** Enter the command **config terminal** to enter configuration mode:

```
Router# config terminal
Router(config)#
```

The router enters global configuration mode, indicated by the Router(config)# prompt.

- Step 5** If you have not configured the router before, or want to change the configuration, configure global parameters, passwords, network management, and routing protocols. In this example, IP routing, AppleTalk routing, and Internetwork Packet Exchange (IPX) routing are all enabled:

```
Router(config)# ip routing
Router(config)# appletalk routing
Router(config)# ipx routing
```

For complete information about global configuration commands, refer to the Cisco IOS configuration guides and command references.

- Step 6** Enter the **controller t1** command to select the CT1/PRI interface to configure. For example, to configure a T1 interface in slot 1 and unit 0, enter the following command:

```
Router(config)# cont t1 1/0
```

- Step 7** Specify the clock source for the module. The **clock source** command determines which end of the circuit provides clocking:

```
Router(config-controller)# clock source line
```

Note The clock source should be set to use internal clocking only for testing the network or if the full T1 line is used as the channel group. Only one end of the T1 line should be set to internal.

- Step 8** Specify the framing type:

```
Router(config-controller)# framing esf
```

- Step 9** Specify the line code format:

```
Router(config-controller)# linecode b8zs
Router(config-controller)#
%CONTROLLER-3-UPDOWN: Controller T1 1, changed state to up
Router(config-controller)#
```

- Step 10** Specify the channel group and time slots to be mapped. The command shown sets the channel group to 0 and selects time slots 1, 3 through 5, and 7 for mapping.

```
Router(config-controller)# channel-group 0 timeslots 1,3-5,7
Router(config-controller)#
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial1/0:0, changed state to down
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial1/0:0, changed state to up
Router(config-controller)#
Router(config-controller)#
```

- Step 11** After you define T1 channel groups, you can configure each channel group as a virtual serial interface. Specify the CT1/PRI interface, unit number, and channel group to modify, as in the following example:

```
Router(config-controller)# int serial 1/0:0
```

- Step 12** Assign an IP address and subnet mask to the interface using the **ip address** command, substituting the IP address and subnet mask for your site:

```
Router(config-if)# ip address 1.1.15.1 255.255.255.0
Router(config-if)#
```

- Step 13** Add any configuration commands needed to enable routing protocols or adjust the interface characteristics. Refer to the Cisco IOS configuration guides and command references for more information.

- Step 14** If your router has more than one CT1/PRI interface, enter the **exit** command to return to the Router(config)# prompt. Repeat Step 6 through Step 13 of this procedure to configure the next CT1/PRI interface.

- Step 15** By default, the router allocates 25 percent of dynamic random-access memory (DRAM) to shared memory (used for data transmitted or received by network modules and WAN interface cards). If your router includes multiple ISDN PRI interfaces, you must increase the amount of shared memory by entering the **memory-size iomem** command. The following example increases shared memory from 25 percent to 40 percent:

```
Router(config)# memory-size iomem 40
```

Note For further information about the **memory-size iomem** command, refer to the Cisco IOS configuration guides and command references.

- Step 16** When you are finished configuring interfaces, exit configuration mode and return to the enable prompt by pressing **Ctrl-Z**. To see the current operating configuration, including any changes you just made, enter the **show running-config** command:

```
Router# show running-config
```

To see the configuration currently stored in NVRAM, enter the command **show startup-config** at the enable prompt.

```
Router# show startup-config
```

- Step 17** The results of the **show running-config** and **show startup-config** commands differ from each other if you have made changes to the configuration, but have not yet written them to NVRAM. To write your changes to NVRAM, making them permanent, enter the command **copy running-config startup-config** at the enable prompt:

```
Router# copy running-config startup-config
Building configuration. . .
[OK]
Router#
```

The router is now configured to boot in the new configuration.

Configuring E1 Interfaces

The following procedure can be used to configure a new CE1/PRI module (balanced or unbalanced) or to change the configuration of an existing module.

To enter configuration mode, follow this procedure:

- Step 1** Connect a console to the router. If you need instructions for connecting a console, refer to the installation chapter of your router installation and configuration guide. Power up the router.
- Step 2** If the current configuration is no longer valid, after about a minute you see the following prompt:

```
Would you like to enter the initial dialog? [yes]:
```

Answer **no**. You now enter the normal operating mode of the router.

Note If the current configuration is valid, you enter the normal operating mode automatically.

- Step 3** After a few seconds you see the user EXEC prompt (Router>). Type **enable** and the password to enter enable mode:

```
Router> enable
Password:
```

Configuration changes can be made only in enable mode. The prompt changes to the privileged EXEC (enable) prompt (Router#):

```
Router#
```

- Step 4** Enter the command **config terminal** to enter configuration mode:

```
Router# config terminal
Router(config)#
```

The router enters global configuration mode, indicated by the Router(config)# prompt.

- Step 5** If you have not configured the router before, or want to change the configuration, configure global parameters, passwords, network management, and routing protocols. In this example, IP routing, AppleTalk routing, and IPX routing are all enabled:

```
Router(config)# ip routing
Router(config)# appletalk routing
Router(config)# ipx routing
```

For complete information about global configuration commands, refer to the Cisco IOS configuration guides and command references.

- Step 6** Enter the **controller e1** command to select the CE1/PRI interface to configure. For example, to configure an E1 interface in slot 1 and unit 0, enter the following command:

```
Router(config)# cont e1 1/0
```

- Step 7** Specify the framing type:

```
Router(config-controller)# framing crc4
```

- Step 8** Specify the channel group and time slots to be mapped. The command shown sets the channel group to 0 and selects time slots 1, 3 through 5, and 7 for mapping:

```
Router(config-controller)# channel-group 0 timeslots 1,3-5,7
Router(config-controller)#
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial1:0, changed state to down
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial1:0, changed state to up
Router(config-controller)#
Router(config-controller)#
```

- Step 9** After you define E1 channel groups, you can configure each channel group as a virtual serial interface. Specify the CE1/PRI interface, unit number, and channel group to modify, as in the following example:

```
Router(config-controller)# int serial 1/0:0
```

- Step 10** Assign an IP address and subnet mask to the interface using the **ip address** command, substituting the appropriate IP address and subnet mask for your site:

```
Router(config-if)# ip address 1.1.15.1 255.255.255.0
Router(config-if)#
```

- Step 11** Add any configuration commands needed to enable routing protocols or adjust the interface characteristics. Refer to the Cisco IOS configuration guides and command references for more information.

- Step 12** If your router has more than one CE1/PRI interface, enter the **exit** command to return to the Router(config)# prompt. Repeat Step 6 through Step 11 of this procedure to configure the next CE1/PRI interface.

- Step 13** By default, the router allocates 25 percent of dynamic random-access memory (DRAM) to shared memory (used for data transmitted or received by network modules and WAN interface cards). If your router includes multiple ISDN PRI interfaces, you must increase the amount of shared memory by entering the **memory-size iomem** command. The following example increases shared memory from 25 percent to 40 percent:

```
Router(config)# memory-size iomem 40
```

Note For further information about the **memory-size iomem** command, refer to the Cisco IOS configuration guides and command references.

- Step 14** When you are finished configuring interfaces, exit configuration mode and return to the enable prompt by pressing **Ctrl-Z**. To see the current operating configuration, including any changes you just made, enter the **show running-config** command:

```
Router# show running-config
```

To see the configuration currently stored in nonvolatile random-access memory (NVRAM), enter the command **show startup-config** at the enable prompt.

```
Router# show startup-config
```

- Step 15** The results of the **show running-config** and **show startup-config** commands differ from each other if you have made changes to the configuration, but have not yet written them to NVRAM. To write your changes to NVRAM, making them permanent, enter the command **copy running-config startup-config** at the enable prompt:

```
Router# copy running-config startup-config
Building configuration. . .
[OK]
Router#
```

The router is now configured to boot in the new configuration.

Obtaining Service and Support

For service and support for a product purchased from a reseller, contact the reseller. Resellers offer a wide variety of Cisco service and support programs, which are described in the section “Service and Support” in the information packet that shipped with your chassis.

Note If you purchased your product from a reseller, you can access Cisco Connection Online (CCO) as a guest. CCO is Cisco Systems’ primary, real-time support channel. Your reseller offers programs that include direct access to CCO’s services.

For service and support for a product purchased directly from Cisco, use CCO.

Cisco Connection Online

CCO is Cisco Systems’ primary, real-time support channel. SMARTnet customers and partners can self-register on CCO to obtain additional content and services.

Note If you purchased your product from a reseller, you can access CCO as a guest. Your reseller offers programs that include direct access to CCO’s services.

Available 24 hours a day, 7 days a week, CCO provides a wealth of standard and value-added services to Cisco's customers and business partners. CCO services include product information, software updates, release notes, technical tips, the Bug Navigator, configuration notes, brochures, descriptions of service offerings, and download access to public and authorized files.

CCO serves a wide variety of users through two interfaces that are updated and enhanced simultaneously—a character-based version and a multimedia version that resides on the World Wide Web (WWW). The character-based CCO supports Zmodem, Kermit, Xmodem, FTP, and Internet e-mail, and is excellent for quick access to information over lower bandwidths. The WWW version of CCO provides richly formatted documents with photographs, figures, graphics, and video, as well as hyperlinks to related information.

You can access CCO in the following ways:

- WWW: <http://www.cisco.com>.
- WWW: <http://www-europe.cisco.com>.
- WWW: <http://www-china.cisco.com>.
- Telnet: cco.cisco.com.
- Modem: From North America, 408 526-8070; from Europe, 33 1 64 46 40 82. Use the following terminal settings: VT100 emulation; databits: 8; parity: none; stop bits: 1; and baud rates up to 14.4 kbps.

For a copy of CCO's Frequently Asked Questions (FAQ), contact cco-help@cisco.com. For additional information, contact cco-team@cisco.com.

Note If you need technical assistance with a Cisco product that is under warranty or covered by a Cisco maintenance contract, contact Cisco's Technical Assistance Center (TAC) at 800 553-2447, 408 526-7209, or tac@cisco.com.

Please use CCO to obtain general information about Cisco Systems, Cisco products, or upgrades. If CCO is not accessible, contact 800 553-6387, 408 526-7208, or cs-rep@cisco.com.

This document is to be used in conjunction with your router installation and configuration guide and the *Regulatory Compliance and Safety Information* document for your router.

AtmDirector, AutoConnect, AutoRoute, AXIS, BPX, Catalyst, CD-PAC, CiscoAdvantage, CiscoFusion, Cisco IOS, the Cisco IOS logo, *CiscoLink*, CiscoPro, the CiscoPro logo, CiscoRemote, the CiscoRemote logo, CiscoSecure, Cisco Systems, CiscoView, CiscoWorks, ClickStart, ControlStream, EdgeConnect, EtherChannel, FairShare, FastCell, FastForward, FastManager, FastMate, FastPADImp, FastPADmicro, FastPADmp, FragmentFree, FrameClass, Fulcrum INS, IGX, Impact, Internet Junction, JumpStart, LAN²LAN Enterprise, LAN²LAN Remote Office, LightSwitch, NetBeyond, NetFlow, Newport Systems Solutions, *Packet*, PIX, Point and Click Internetworking, RouteStream, Secure/IP, SMARTnet, StrataSphere, StrataSphere BILLder, StrataSphere Connection Manager, StrataSphere Modeler, StrataSphere Optimizer, Stratm, StrataView Plus, StreamView, SwitchProbe, SwitchVision, SwitchWare, SynchroniCD, *The Cell*, The FastPacket Company, TokenSwitch, TrafficDirector, Virtual EtherSwitch, VirtualStream, VlanDirector, Web Clusters, WNIC, Workgroup Director, Workgroup Stack, and XCI are trademarks; Access by Cisco, Bringing the Power of Internetworking to Everyone, Enter the Net with MultiNet, and The Network Works. No Excuses. are service marks; and Cisco, the Cisco Systems logo, CollisionFree, Combinet, EtherSwitch, FastHub, FastLink, FastNIC, FastPacket, FastPAD, FastSwitch, ForeSight, Grand, Grand Junction, Grand Junction Networks, the Grand Junction Networks logo, HSSI, IGRP, IPX, Kalpana, the Kalpana logo, LightStream, MultiNet, MultiWare, OptiClass, Personal Ethernet, Phase/IP, RPS, StrataCom, TGV, the TGV logo, and UniverCD are registered trademarks of Cisco Systems, Inc. All other trademarks, service marks, registered trademarks, or registered service marks mentioned in this document are the property of their respective owners.

Copyright © 1996, Cisco Systems, Inc.
All rights reserved. Printed in USA.
969R

