

Preparing for Installation

This chapter provides safety information and describes the tasks you must perform before you install the LightStream 100 ATM switch.

This chapter contains the following sections:

- Safety Recommendations
- Installation Environmental Conditions
- Confirming the Contents of the Shipping Container
- LightStream 100 ATM Switch Components

Safety Recommendations

The following guidelines will help to ensure your general safety and protect the equipment:

- Keep the chassis area clear and dust-free during and after installation.
- Put the removed chassis cover in a safe place.
- Keep tools away from walk areas where you and others could fall over them.
- Do not wear loose clothing that could get caught in the chassis. Fasten your tie or scarf and roll up your sleeves.
- Wear safety glasses if you are working under any conditions that might be hazardous to your eyes.
- Do not perform any action that creates a potential hazard to people or makes the equipment unsafe.

Safety Recommendations



Warning Class 1 laser product. To see this warning in multiple languages, refer to the “Class 1 Laser Product Warning” section in the “Translated Safety Warnings” appendix.



Warning Do not stare into the beam or view it directly with optical instruments. To see this warning in multiple languages, refer to the “Laser Beam Warning” section in the “Translated Safety Warnings” appendix.

Maintaining Safety with Electricity

Follow these guidelines when working on equipment powered by electricity:



Warning Before working on a chassis or working near power supplies, unplug the power cord on AC units; disconnect the power at the circuit breaker on DC units. To see this warning in multiple languages, refer to the “Power Supply Disconnection Warning” section in the “Translated Safety Warnings” appendix.



Warning The device is designed to work with TN power systems. To see this warning in multiple languages, refer to the “TN Power Warning” section in the “Translated Safety Warnings” appendix.

- Locate the emergency power-off switch for the room in which you are working. Then, if an electrical accident occurs, you can act quickly to turn OFF the power.
- Before working on the system, turn OFF the power and unplug the power cord.
- Disconnect all power before doing the following:
 - Installing or removing a chassis
 - Working near power supplies
 - Performing a software upgrade
- Do not work alone if potentially hazardous conditions exist.
- Never assume that power is disconnected from a circuit. Always check.

- Look carefully for possible hazards in your work area, such as moist floors, ungrounded power extension cables, and missing safety grounds.
- If an electrical accident occurs, proceed as follows:
 - Use caution; do not become a victim yourself.
 - Turn off power to the system.
 - If possible, send another person to get medical aid. Otherwise, assess the condition of the victim and then call for help.
 - Determine if the person needs rescue breathing or external cardiac compressions; then take appropriate action.

Preventing Electrostatic Discharge Damage

Electrostatic discharge (ESD) can damage equipment and impair electrical circuitry. It occurs when electronic components are improperly handled and can result in complete or intermittent failures.

Always follow ESD-prevention procedures when removing and replacing components. Ensure that the chassis is electrically connected to earth ground. Wear an ESD-preventive wrist strap, ensuring that it makes good skin contact. Connect the clip to an unpainted chassis frame surface to safely channel unwanted ESD voltages to ground. To properly guard against ESD damage and shocks, the wrist strap and cord must operate effectively. If no wrist strap is available, ground yourself by touching the metal part of the chassis.



Caution For safety, periodically check the resistance value of the antistatic strap, which should be within the range of 1 and 10 megohms (Mohms).

Installation Environmental Conditions

Install the LightStream 100 ATM switch in an area that meets the following conditions:

- 1 Make sure the LightStream 100 switch remains operational within the temperature and humidity limits shown in Table 1-3.
- 2 Allow the following minimum vacant space surrounding the LightStream 100 switch to ensure proper heat radiation:
 - 10 cm (approximately 4 inches) or more—sides
 - 10 cm (approximately 4 inches) or more—front and rear
 - 10 cm (approximately 4 inches) or more—top
- 3 Make sure the installation site meets the following criteria:
 - Protected from water and chemicals
 - Free of shock and vibration
 - Horizontal
 - Free of excessive dust
 - Away from direct sunlight
 - Away from devices that generate strong magnetism (for example, a TV or speakers)

Confirming the Contents of the Shipping Container

This section provides information about the contents of containers used to transport the LightStream 100 ATM switch.

The LightStream 100 switch comes in two containers: the LightStream 100 main unit container and the LINF card container. Ensure that the containers are labeled with each type of equipment before opening them.

The LightStream 100 main unit includes the following parts:

- Motherboard (P-8X84)
- Bus converter (BCONV) card (P-8X54)

- Center card (P-8X55-A)
- Processor (PROC) card (FSB3523GX, P-8X0R)
- Gateway Packet Assembler/Disassembler (GWPAD) card (P-8X86[002])
- Fans (three units)
- Power supply
- Slot covers (16 units)
- Shielded power cable (one unit)

The LINF card box contains the LINF card set (a LINF card and front panel with window):

- STS-3c/STM-1 LINF card (P-8X79, P-8X0K)
- Transparent Asynchronous Transmitter/Receiver Interface (TAXI) LINF card (P-8X31, P-8X85)

Note The quantity and type of cards depend on your system configuration.

LightStream 100 ATM Switch Components

References throughout this publication refer to the LightStream 100 ATM switch front and rear panel layouts. Figure 2-1 shows the front panel layout, and Figure 2-2 shows the rear panel layout. Figure 2-3 and Figure 2-4 show LightStream 100 switch internal views.

LightStream 100 ATM Switch Components

Figure 2-1 LightStream 100 ATM Switch Front Panel






Figure 2-2 LightStream 100 ATM Switch Rear Panel



LightStream 100 ATM Switch Components


Figure 2-3 LightStream 100 ATM Switch Internal View



GWPAD : Gateway Packet Assembler/Disassembler
LINF : Line Interface
BCONV : Bus Converter
PROC : Processor
VME : Versa Module Eurocard

H2587

Figure 2-4 Expanded Internal View (Motherboard)



ATOM SW : Asynchronous Transfer Mode Output-Buffer Modular Switch
CLKGEN : Clock Generator
DMUX : Demultiplexer
GWPAD : Gateway Packet Assembler/Disassembler
LINF : Line Interface
MUX : Multiplexer

H2567

LightStream 100 ATM Switch Components
