



Doc. No. 78-2985-01 Rev. A0

LightStream 1010 ATM Switch Power Supply Configuration Note

Product Number: L1010-PWR-1=

This document contains instructions for installing and configuring the LightStream 1010 ATM switch power supply. For complete hardware configuration and maintenance procedures, refer to the *LightStream 1010 ATM Switch User Guide* publication.

Cisco documentation and additional literature are available on a CD called Cisco Connection Documentation, Enterprise Series. The CD is updated and shipped monthly, so it might be more up-to-date than the printed documentation. To order the Cisco Connection Documentation, Enterprise Series CD, contact your local sales representative or call Customer Service. The CD is available both as a single CD and as an annual subscription. You can access Cisco technical documentation on the World Wide Web Universal Resources Locator (URL)

<http://www.cisco.com>.

Sections in this document include the following:

- What is the LightStream 1010 ATM Switch?
- Power Supplies
- Power Supply LEDs
- Preparing Network Connections
- Safety Recommendations
- Installing and Replacing Power Supplies




Warning Only trained and qualified personnel should install or replace the LightStream 1010 ATM switch, chassis, power supplies, fan assembly, or modules.

What is the LightStream 1010 ATM Switch?

The LightStream 1010 uses a five-slot, modular chassis featuring the option of dual, fault-tolerant, load-sharing power supplies. (See Figure 1.) The central slot in the LightStream 1010 is dedicated to a single, field-replaceable ATM switch processor (ASP) module that supports both the 5-Gbps shared memory and the fully nonblocking switch fabric. The ASP also supports the feature card and high performance reduced instruction set (RISC) processor that provides the central intelligence for the

device. The remaining slots support up to four hot-swappable Carrier Modules (CAMs). Each CAM supports up to two hot-swappable Port Adapter Modules (PAMs) for a maximum of eight PAMs per switch, supporting a wide variety of desktop, backbone, and wide-area interfaces.

Figure 1 Front View of the LightStream 1010 ATM Switch



The LightStream 1010 ATM switch provides switched ATM connections to individual workstations, servers, LAN segments, or other ATM switches and routers using fiber-optic, unshielded twisted-pair (UTP), and coaxial cable.

Figure 2 shows an example of a network configuration using the LightStream 1010 ATM switch in a high-performance workgroup.

Figure 2 LightStream 1010 Workgroup Configuration Example





Figure 3 shows an example of a network configuration using the LightStream 1010 ATM switch for a campus backbone.

Figure 3 LightStream 1010 Backbone Configuration Example



Power Supplies

The LightStream 1010 ATM switch comes equipped with one 350W, AC-input power supply. An identical, optional, second power supply is also available for fault-tolerant power. Dual power supplies are automatically load-sharing and redundant, which means that a second power supply can be installed or replaced without interrupting system operation.

Fault-Tolerant Power

When two power supplies are installed and both are turned on, each concurrently provides about half of the required power to the system. If one of the power supplies fails, the second power supply immediately ramps up to full power to maintain uninterrupted system operation. Load-sharing and fault-tolerance are automatically enabled when the second power supply is installed; no software configuration is required.

Each power supply can be connected to a separate AC source so that, in case of an input power line or power supply failure, the second power supply maintains uninterrupted system power.

Specifications

Table 1 lists the LightStream 1010 ATM switch and power supply specifications:

Table 1 LightStream 1010 ATM Switch and Power Supply Specifications

Description	Specifications
Dimensions (H x W x D)	10.4 x 17.25 x 18.4" (26.4 x 43.1 x 46.0 cm) Chassis depth including cable guide is 21.64" (55.0 cm) (L1010-BASE5)
Weight	9.55 lb (4.40 kg)
Operating temperature	32 to 104 F (0 to 40 C)
Nonoperating temperature	-40 to 167 F (-40 to 75 C)
Humidity	10 to 90%, noncondensing
Altitude	-500 to 10,000 ft (-52 to 3,048 m)
Microprocessor	100-MHz MIPs R4600
Connections	32,000 point-to-point, 2,048 multi-to-multipoint VC and VP switching, VP tunneling PVC and SVC F4 and F5 OAM ¹ segment and end-to-end flows, RDI ² and AIS ³ OAM PING on IP or ATM address
Mean Time Between Failures	2.6 years for system configuration
Agency approvals	Safety: UL ⁴ 1950, CSA ⁵ -C22.2 No. 950-93, and EN60950 EMI ⁶ : FCC Class A CE Mark, and VCCI Class II with shielded cables

1. OAM = Operations, Administration, and Maintenance
2. RDI = remote defect identification
3. AIS = alarm indication signal
4. UL = Underwriters Laboratory
5. CSA = Canadian Standards Association
6. EMI = electromagnetic interference

Maximum Configuration

The eight available PAMs support any combination of network interfaces to provide the following maximum port densities:

- Up to 32 155 multimode fiber-optic ports
- Up to 32 155 single-mode fiber-optic ports
- Up to 32 155 UTP ports
- Up to 16 DS-3 coaxial ports
- Up to 16 E3 coaxial ports
- Up to 8 622-Mbps OC-12 single-mode ports
- Up to 8 622-Mbps OC-12 multimode ports

You can install any combination of PAMs in any of the eight available PAM slots. There are no restrictions on either the number of modules that can be installed or their proximity to the ASP.

Power Supply LEDs

Each power supply has one LED. The LED is green when the power supply is powered on and operating within tolerances. The LED is off when the power supply is powered off, the power cord is disconnected, or if the power supply has malfunctioned.

See the section “ASP LEDs” for a description of the PS0 and PS1 LEDs on the ASP.

ASP LEDs

The LEDs on the ASP indicate the status of the system, which includes the fan assembly and power supply(ies) and the ASP. The ASP LEDs are shown in Figure 4 and described in Table 2.

Figure 4 ATM Switch Processor LEDs




Table 2 ATM Switch Processor LEDs

LED	Description
Status	The switch performs a series of self-tests and diagnostic tests. If all the tests pass, the status LED is green. If any test fails, the status LED is red. During system boot or if the module is disabled, the LED is orange.
Fan	Indicates whether or not the fan is operational. If the fan is operational, the fan LED is green. If the fan is not operational, the fan LED is red.
PS 0, left bay	If the power supply is operational, the PS0 LED is green. If the power supply is installed but not operational, the PS0 LED is red. If the power supply is off or not installed, the PS0 LED is off.
PS 1, right bay	If the power supply is operational, the PS1 LED is green. If the power supply is installed but not operational, the PS1 LED is red. If the power supply is not installed, the PS1 LED is off.
Link	Green—The Ethernet port is operational. Off—No signal is detected.
RX (Receive)	Off—No signal received. Flashing green—Ethernet packets being received: pulse rate increases with data rate.
TX (Transmit)	Off—Not transmitting. Flashing green—Ethernet packets being transmitted: pulse rate increases with data rate.

Power Supply Monitoring

The power supplies are self-monitoring. Each power supply monitors its own temperature and internal voltages.

Environmental Monitoring and Reporting Functions

The environmental monitoring and reporting functions enable you to maintain normal system operation by identifying and resolving adverse conditions before the system fails. Environmental monitoring functions constantly monitor the internal chassis air temperature. Each power supply monitors its own voltage and shuts itself down if it detects a critical condition within the power supply. The reporting functions enable you to retrieve and display the present values of measured parameters, and the reporting functions display alarms on the console if any of the monitored parameters exceed defined thresholds.

Environmental Monitoring

The environmental monitoring functions use three levels of status conditions to monitor the system: normal, alarm, and critical. The processor monitors the temperature inside the module compartment, and the power supplies use the normal and critical levels to monitor DC voltages. Table 3 lists temperature thresholds for the processor-monitored levels. Table 4 lists the DC power thresholds for the normal and critical power-supply-monitored levels.

Table 3 Processor-Monitored Temperature Thresholds

Parameter	Normal	Alarm
Airflow	10 to 55 C	> 55 C

Table 4 Power-Supply-Monitored Voltage Thresholds

Parameter	Critical	Normal	Critical
+5V	< 4.74V	4.74–5.26V	> 5.26V

The three levels of status condition includes:

- Normal—all monitored parameters are within normal tolerances.
- Alarm—an out-of-tolerance temperature or voltage condition exists. The system may not continue operation. If a voltage measurement reaches this level, the power supply can shut down the system. Immediate action is required. The +12 VDC line remains enabled to allow the fan assembly to continue operation.

The power supply monitors its own internal temperature and voltages. The power supply is either within tolerance (normal) or out of tolerance (alarm level), as shown in Table 4. If an internal-power-supply temperature or voltage reaches a critical level, the power supply shuts down without any interaction with the processor.

Preparing Network Connections

When preparing your site for network connections to the switch, you need to consider a number of factors related to each type of interface:

- Type of cabling required for each type (fiber, twisted-pair, or coaxial cabling).
- Distance limitations for each signal type.
- Specific cables you need to connect each interface.
- Any additional interface equipment you need, such as transceivers, modems, channel service units (CSUs), or data service units (DSUs). Before installing the switch, have all additional external equipment and cables on hand. If you intend to build your own cables, refer to the cable pinouts in the section “Installing the LightStream 1010 Switch” in the *LightStream 1010 ATM Switch User Guide* publication. For ordering information, contact a customer service representative.

Distance Limitations

The length of your networks and the distances between connections depend on the type of signal, the signal speed, and the transmission media (the type of cabling used to transmit the signals). For example, fiber-optic cable has a greater channel capacity than twisted-pair cabling. The following distance limits are provided as guidelines for planning your network connections before installation.

For Further Reference

The following publications contain information on determining attenuation and power budget:

- T1E1.2/92-020R2 ANSI, the Draft American National Standard for Telecommunications entitled “Broadband ISDN Customer Installation Interfaces: Physical Layer Specification.”
- *Power Margin Analysis*, AT&T Technical Note, TN89-004LWP, May 1989.

Safety Recommendations

The following guidelines help ensure your safety and protect the equipment. This list is not inclusive of all potentially hazardous situations that you may be exposed to as you install the module, so *be alert*.

- Never try to lift the chassis by yourself; *two people are required* to lift the switch.
- Always turn off all power supplies and unplug all power cords before removing the chassis front panel.
- Always unplug all power cords before installing or removing a chassis.
- Keep the chassis area clear and dust free during and after installation.
- Keep tools and chassis components away from walk areas.
- Do not wear loose clothing, jewelry (including rings and chains), or other items that could get caught in the chassis. Fasten your tie or scarf and sleeves.



Warning Metal objects heat up when connected to power and ground, and can cause serious burns.

Safety with Electricity

The supervisor engine, modules, and redundant (second) power supplies are designed to be removed and replaced while the system is operating without presenting an electrical hazard or damage to the system. Before removing a redundant power supply, ensure that the first supply is powered on. However, you must shut down the system before removing or replacing any of the replaceable components inside the front panel, for example, the backplane. Never install equipment that appears damaged.

Follow these basic guidelines when working with any electrical equipment:

- Before beginning any procedures requiring access to the chassis interior, locate the emergency power-off switch for the room in which you are working.
- Disconnect all power and external cables before installing or removing a chassis.
- Do not work alone when potentially hazardous conditions exist.
- Never assume that power has been disconnected from a circuit; always check.
- Do not perform any action that creates a potential hazard to people or makes the equipment unsafe.
- Carefully examine your work area for possible hazards such as moist floors, ungrounded power extension cables, and missing safety grounds.

In addition, use the guidelines that follow when working with any equipment that is disconnected from a power source but still connected to telephone wiring or other network cabling.



Warning Do not work on the system or connect or disconnect cables during periods of lightning activity.

- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.

Installing and Replacing Power Supplies

The switch is configured to your order and is ready for installation and startup when it leaves the factory. As your communication requirements change, you may want to upgrade your system and add or replace a power supply. This section describes the procedures for installing, replacing, and reconfiguring power supplies.

The 376W power supplies (AC-input) are used in the switch support redundant hot swapping. When two power supplies are installed, you can remove or replace one of the supplies without affecting system operation. When power is removed from one supply, the redundant power feature causes the second supply to ramp up to full power and maintain uninterrupted system operation. In systems with dual power supplies, connect each power supply to separate input lines so that, in case of a line failure, the second source is still available and can maintain maximum overcurrent protection for each power connection.

A modular power cord connects each power supply to the separate site power sources.



Caution Use both hands to remove and install power supplies.

Note Each power supply weighs 11 pounds (4.98 kilograms).



Caution Keep hands and fingers out of the power-supply bays. High voltage is present on the power backplane when the system is operating.

Tools Required

You need a 1/4-inch flat-blade screwdriver to remove and install filler plates and to loosen or tighten the captive installation screws on the power supply.

Removing Power Supplies

Always install a filler plate over an empty power supply bay to protect the connectors from contamination.


Take the following steps to remove a power supply:

Step 1 Turn OFF the power switch on the power supply you are removing. (See Figure 5.)



Caution Failure to turn off the power supply could result in equipment damage.

Figure 5 Power-Supply Switch and AC Connection




Step 2 Disconnect the power cord from the power source.


Step 3 Remove the power cord from the power inlet.

Step 4 Use a screwdriver to loosen and remove the captive installation screws on the sides of the supply. (See Figure 6.)

Figure 6 Power-Supply Installation



Step 5 Grasp the power-supply handle with one hand and place your other hand underneath to support the bottom of the supply, as shown in Figure 7.

Figure 7 Handling a Power Supply

Step 6 Pull the supply out of the bay and put it aside.

Step 7 If the power-supply bay is to remain empty, install a blank power-supply filler plate (part number 700-00177-01) over the opening and secure it with the mounting screws. This precaution protects the inner chassis from dust, as well as the connectors in the rear of the bay, which expose current levels when the chassis is powered on.

Step 8 Replace the power supply by following Step 1 through Step 5 in reverse.



Caution Keep hands and fingers out of the power-supply bays. High voltage is present on the power backplane when the system is operating.

Cisco Connection Online

Cisco Connection Online (CCO), formerly Cisco Information Online (CIO), is Cisco Systems' primary, real-time support channel. Maintenance customers and partners can self-register on CCO to obtain additional content and services.

Available 24 hours a day, 7 days a week, CCO provides a wealth of standard and value-added services to Cisco's customers and business partners. CCO services include product information, software updates, release notes, technical tips, the Bug Navigator, configuration notes, brochures, descriptions of service offerings, and download access to public and authorized files.

CCO serves a wide variety of users through two interfaces that are updated and enhanced simultaneously—a character-based version and a multimedia version that resides on the World Wide Web (WWW). The character-based CCO supports Zmodem, Kermit, Xmodem, FTP, Internet e-mail, and fax download options, and is excellent for quick access to information over lower bandwidths. The WWW version of CCO provides richly formatted documents with photographs, figures, graphics, and video, as well as hyperlinks to related information.

You can access CCO in the following ways:

- WWW: <http://www.cisco.com>.
- Telnet: [cco.cisco.com](telnet://cco.cisco.com).
- Modem: From North America, 408 526-8070; from Europe, 33 1 64 46 40 82. Use the following terminal settings: VT100 emulation; databits: 8; parity: none; stop bits: 1; and baud rates up to 14.4 kbps.

For a copy of CCO's Frequently Asked Questions (FAQ), contact cco-help@cisco.com. For additional information, contact cco-team@cisco.com.

Note If you are a network administrator and need personal technical assistance with a Cisco product that is under warranty or covered by a maintenance contract, contact Cisco's Technical Assistance Center (TAC) at 800 553-2447, 408 526-7209, or tac@cisco.com. To obtain general information about Cisco Systems, Cisco products, or upgrades, contact 800 553-6387, 408 526-7208, or cs-rep@cisco.com.

This document is to be used in conjunction with the *LightStream 1010 ATM Switch User Guide* and the *LightStream 1010 ATM Switch Command Reference* publication.

AtmDirector, Catalyst, CD-PAC, CiscoAdvantage, CiscoFusion, Cisco IOS, the Cisco IOS logo, *CiscoLink*, CiscoPro, the CiscoPro logo, CiscoRemote, the CiscoRemote logo, CiscoSecure, Cisco Systems, CiscoView, CiscoVision, CiscoWorks, ClickStart, ControlStream, EtherChannel, FastCell, FastForward, FastManager, FastMate, FragmentFree, HubSwitch, Internet Junction, LAN²LAN Enterprise, LAN²LAN Remote Office, LightSwitch, Newport Systems Solutions, *Packet*, Phase/IP, PIX, Point and Click Internetworking, RouteStream, Secure/IP, SMARTnet, StreamView, SwitchProbe, SwitchVision, SwitchWare, SynchroniCD, *The Cell*, TokenSwitch, TrafficDirector, Virtual EtherSwitch, VirtualStream, VlanDirector, Web Clusters, WNIC, Workgroup Director, Workgroup Stack, and XCI are trademarks; Access by Cisco, Bringing the Power of Internetworking to Everyone, Enter the Net with MultiNet, and The Network Works. No Excuses, are service marks; and Cisco, the Cisco Systems logo, CollisionFree, Combinet, EtherSwitch, FastHub, FastLink, FastNIC, FastSwitch, Grand, Grand Junction, Grand Junction Networks, the Grand Junction Networks logo, HSSI, IGRP, Kalpana, the Kalpana logo, LightStream, MultiNet, MultiWare, Personal Ethernet, TGV, the TGV logos, and UniverCD are registered trademarks of Cisco Systems, Inc. All other trademarks, service marks, registered trademarks, or registered service marks mentioned in this document are the property of their respective owners.

Copyright © 1996, Cisco Systems, Inc.
All rights reserved. Printed in USA.
965R