

ATM Commands

This chapter describes the function and displays the syntax of each ATM command. For more information about defaults and usage guidelines, see the corresponding chapter of the *Router Products Command Reference* publication.

atm aal aal3/4

To enable a subinterface supporting ATM adaptation layer 3/4 (AAL3/4) on an ATM interface, use the **atm aal aal3/4** interface configuration command.

atm backward-max-burst-size-clp0 *cell-count* **no atm backward-max-burst-size-clp0**

To change the maximum number of high-priority cells coming from the destination router to the source router at the burst level on the switched virtual circuit (SVC), use the **atm backward-max-burst-size-clp0** map-class configuration command. The **no** form of this command restores the default.

cell-count Maximum number of high-priority cells coming from the destination router at the burst level. The default is -1.

atm backward-max-burst-size-clp1 *cell-count* **no atm backward-max-burst-size-clp1**

To change the maximum number of low-priority cells coming from the destination router to the source router at the burst level on the SVC, use the **atm backward-max-burst-size-clp1** map-class configuration command. The **no** form of this command restores the default value.

cell-count Maximum number of low-priority cells coming from the destination router at the burst level. The default is -1.

```
atm backward-peak-cell-rate-clp0 rate  
no atm backward-peak-cell-rate-clp0
```

To change the peak rate of high-priority cells coming from the destination router to the source router on the SVC, use the **atm backward-peak-cell-rate-clp0** map-class configuration command. The **no** form of this command restores the default.

rate Maximum rate in kilobits per second (kbps) that this SVC can receive high-priority cells from the destination router. The default is –1. Maximum value is 155,000 kbps.

```
atm backward-peak-cell-rate-clp1 rate  
no atm backward-peak-cell-rate-clp1
```

To change the peak rate of low-priority cells coming from the destination router to the source router on the SVC, use the **atm backward-peak-cell-rate-clp1** map-class configuration command. The **no** form of this command restores the default.

rate Maximum rate in kilobits per second (kbps) that this SVC can receive low-priority cells from the destination router. The default is –1. Maximum value is 155,000 kbps.

```
atm backward-sustainable-cell-rate-clp0 rate  
no atm backward-sustainable-cell-rate-clp0
```

To change the sustainable rate of high-priority cells coming from the destination router to the source router on the SVC, use the **atm backward-sustainable-cell-rate-clp0** map-class configuration command. The **no** form of this command restores the default.

rate Sustainable rate in kilobits per second (kbps) that this SVC can receive high-priority cells from the destination router. The default is –1. Maximum value is 155,000 kbps.

atm backward-sustainable-cell-rate-clp1 *rate*
no atm backward-sustainable-cell-rate-clp1

To change the sustainable rate of low-priority cells coming from the destination router to the source router on the SVC, use the **atm backward-sustainable-cell-rate-clp1** map-class configuration command. The **no** form of this command restores the default value.

rate Sustainable rate in kilobits per second (kbps) that this SVC can receive low-priority cells from the destination router. The default is –1. Maximum value is 155,000 kbps.

[no] atm clock internal

To cause the AIP to generate the transmit clock internally, use the **atm clock internal** interface configuration command. The **no** form of this command restores the default value.

atm exception-queue *number*
no atm exception-queue

To set the exception-queue length, use the **atm exception-queue** interface configuration command. The **no** form of this command restores the default value.

number Number of entries, in the range of 8 to 256. The default is 32 entries.

atm forward-max-burst-size-clp0 *cell-count*
no atm forward-max-burst-size-clp0

To change the maximum number of high-priority cells going from the source router to the destination router at the burst level on the SVC, use the **atm forward-max-burst-size-clp0** map-class configuration command. The **no** form of this command restores the default value.

cell-count Maximum number of high-priority cells going from the source router at the burst level. The default is –1.

atm forward-max-burst-size-clp1 *cell-count*
no atm forward-max-burst-size-clp1

To change the maximum number of low-priority cells going from the source router to the destination router at the burst level on the SVC, use the **atm forward-max-burst-size-clp1** map-class configuration command. The **no** form of this command restores the default value.

cell-count Maximum number of low-priority cells going from the source router at the burst level. The default is –1.

atm forward-peak-cell-rate-clp0 *rate*
no atm forward-peak-cell-rate-clp0

To change the peak rate of high-priority cells going from the source router to the destination router on the SVC, use the **atm forward-peak-cell-rate-clp0** map-class configuration command. The **no** form of this command restores the default value.

rate Maximum rate in kilobits per second (kbps) that this SVC can send high-priority cells from the source router. The default is –1. The maximum value is 155,000 kbps.

atm forward-peak-cell-rate-clp1 *rate*
no atm forward-peak-cell-rate-clp1

To change the peak rate of low-priority cells coming from the source router to the destination router on the SVC, use the **atm forward-peak-cell-rate-clp1** map-class configuration command. The **no** form of this command restores the default value.

rate Maximum rate in kilobits per second (kbps) that this SVC can send low-priority cells from the source router. The default is –1. The maximum value is 155,000 kbps.

atm forward-sustainable-cell-rate-clp0 *rate*
no atm forward-sustainable-cell-rate-clp0

To change the sustainable rate of high-priority cells coming from the source router to the destination router on the SVC, use the **atm forward-sustainable-cell-rate-clp0** map-class configuration command. The **no** form of this command restores the default value.

rate Sustainable rate in kilobits per second (kbps) that this SVC can send high-priority cells from the source router. The default is –1. The maximum value is 155,000 kbps.

atm forward-sustainable-cell-rate-clp1 *rate*
no atm forward-sustainable-cell-rate-clp1

To change the sustainable rate of low-priority cells coming from the source router to the destination router on the SVC, use the **atm forward-sustainable-cell-rate-clp1** map-class configuration command. The **no** form of this command restores the default value.

rate Sustainable rate in kilobits per second (kbps) that this SVC can send low-priority cells from the source router. The default is –1. Maximum value is 155,000 kbps.

atm maxvc *number*
no atm maxvc

To set the ceiling value of the virtual circuit descriptor (VCD) on the AIP card, use the **atm maxvc** interface configuration command. The **no** form of this command restores the default value.

number Maximum number of supported virtual circuits. Valid values are 256, 512, 1024, 2048, or 4096. The default is 4096.

atm mid-per-vc *maximum*

To limit the number of message identifier (MID) numbers allowed on each virtual circuit, use the **atm mid-per-vc** interface configuration command.

maximum Number of MIDs allowed per virtual circuit on this interface. The values allowed are 16, 32, 64, 128, 256, 512, and 1024. The default is 16 MIDs per virtual circuit.

atm multicast *address*

To assign an SMDS E.164 multicast address to the ATM subinterface that supports AAL3/4 and SMDS encapsulation, use the **atm multicast** interface configuration command.

address Multicast E.164 address assigned to the subinterface.

atm nsap-address *nsap-address*
no atm nsap-address

To set the NSAP address for an ATM interface using SVC mode, use the **atm nsap-address** interface configuration command. The **no** form of this command removes any configured address for the interface.

nsap-address 40-digit (hexadecimal) NSAP address of this interface (the source address).

[no] atm pvc *vcd vpi vci aal-encap [[midlow midhigh] [peak average burst]]*

To create a permanent virtual circuit (PVC) on the AIP interface, use the **atm pvc** interface configuration command. The **no** form of this command removes the specified PVC.

<i>vcd</i>	Virtual circuit descriptor. Unique number per AIP that identifies to the AIP which VPI/VCI to use for a particular packet. Valid values range from 1 to the value set with the atm maxvc command. The AIP requires this feature to manage packet transmission. The <i>vcd</i> is not associated with the VPI/VCI used for the ATM network cells.
<i>vpi</i>	ATM network virtual path identifier (VPI) of this PVC, in the range from 0 through 255. The VPI is an 8-bit field in the header of the ATM cell. The VPI value is unique only on a single interface, not throughout the ATM network (it has local significance only). Both <i>vpi</i> and <i>vci</i> cannot be specified as 0; if one is 0, the other cannot be 0.
<i>vci</i>	ATM network virtual channel identifier (VCI) of this PVC, in the range of 0 through 65535. The VCI is a 16-bit field in the header of the ATM cell. The VCI value is unique only on a single interface, not throughout the ATM network (it has local significance only). Both <i>vpi</i> and <i>vci</i> cannot be specified as 0; if one is 0, the other cannot be 0.

<i>aal-encap</i>	ATM adaptation layer (AAL) and encapsulation type. When aal5mux is specified, a protocol is also required. Possible values are as follows:
	<ul style="list-style-type: none"> • aal34smds (encapsulation for SMDS networks) • aal5nlpid (encapsulation that allows ATM interfaces to interoperate with HSSI interfaces that are using an ADSU and running ATM-DXI) • aal5mux decnet (a MUX-type virtual circuit) • aal5mux ip (a MUX-type virtual circuit) • aal5mux novell (a MUX-type virtual circuit) • aal5mux vines (a MUX-type virtual circuit) • aal5mux xns (a MUX-type virtual circuit) • aal5snap (LLC/SNAP precedes the protocol datagram) • qsaal (a signaling-type PVC used for setting up or tearing down SVCs)
<i>midlow</i>	(Optional) Starting message identifier (MID) number for this PVC. The default is 0. If you set the <i>peak</i> , <i>average</i> , and <i>burst</i> values, you must also set the <i>midlow</i> and <i>midhigh</i> values.
<i>midhigh</i>	(Optional) Ending MID number for this PVC. The default is 0. If you set the <i>peak</i> , <i>average</i> , and <i>burst</i> values, you must also set the <i>midlow</i> and <i>midhigh</i> values.
<i>peak</i>	(Optional) Maximum rate (in kbps) at which this virtual circuit can transmit. Valid values are in the range from 1 to the maximum rate set for a rate queue. If you set this value, you must also specify a value for the <i>average</i> , <i>burst</i> , <i>midlow</i> and <i>midhigh</i> arguments.

<i>average</i>	(Optional) Average rate (in kbps) at which this virtual circuit will transmit. Valid values are in the range from 1 to the maximum rate set for a rate queue. If you set this value, you must also specify a value for the <i>peak</i> , <i>burst</i> , <i>midlow</i> and <i>midhigh</i> arguments.
<i>burst</i>	(Optional) Value (in the range 1 through 2047) that relates to the maximum number of ATM cells the virtual circuit can transmit to the network at the <i>peak</i> rate of the PVC. The actual burst cells equals <i>burst</i> * 32 cells, thereby allowing for a burst size of 32 cells to 65504 cells. The largest practical value of <i>burst</i> is the MTU size of the AIP card. If you set this value, you must also specify a value for the <i>average</i> , <i>peak</i> , <i>midlow</i> and <i>midhigh</i> arguments.

atm rate-queue *queue-number speed*

no atm rate-queue

To create a permanent rate queue for the AIP, use the **atm rate-queue** interface configuration command. The **no** form of this command removes the rate queue.

<i>queue-number</i>	Queue number in the range 0 through 7.
<i>speed</i>	Speed in Mbps in the range from 1 through 155. The maximum speed is determined by the detected PLIM type on the AIP: <ul style="list-style-type: none"> • 34 Mbps for E3 • 45 Mbps for DS3 (when available) • 100 Mbps for TAXI • 155 Mbps for SONET

atm rawq-size *number*
no atm rawq-size

To define the AIP raw queue size, use the **atm rawq-size** interface configuration command. The **no** form of this command restores the default value.

number Maximum number of cells in the raw queue simultaneously, in the range 8 through 256. The default is 32.

atm rxbuff *number*
no atm rxbuff

To set the maximum number of Receive buffers for simultaneous packet reassembly, use the **atm rxbuff** interface configuration command. The **no** form of this command restores the default value.

number Maximum number of packet reassemblies that the AIP can perform simultaneously, in the range 0 through 512. The default is 256.

atm smds-address *address*

To assign a unicast E.164 address to the ATM subinterface that supports AAL3/4 and SMDS encapsulation, use the **atm smds-address** interface configuration command.

address Unicast E.164 address assigned to the subinterface.

[no] atm sonet stm-1

To set the proper mode of operation for the SONET PLIM, use the **atm sonet stm-1** interface configuration command. The **no** form of this command restores the default (STS-3C).

atm txbuff *number*

no atm txbuff

To set the maximum number of Transmit buffers for simultaneous packet fragmentation, use the **atm txbuff** interface configuration command.

The **no** form of this command restores the default value.

number Maximum number of packet fragmentations that the AIP can perform simultaneously, in the range 0 through 512. The default is 256.

atm vc-per-vp *number*

no atm vc-per-vp

To set the maximum number of VCIs to support per VPI, use the **atm vc-per-vp** interface configuration command. The **no** form of this command restores the default value.

number Maximum number of VCIs to support per VPI. Valid values are 32, 64, 128, 256, 512, 1024, 2048, or 4096. The default is 1024.

atm vp-filter *hexvalue*

no atm vp-filter

To set the AIP filter register, use the **atm vp-filter** interface configuration command. The **no** form of this command restores the default value.

hexvalue Value in hexadecimal format. The default is 0x7B.

[**no**] **protocol** *protocol-address* **atm-nsap** *atm-nsap-address*
[**class** *class-name*] [**broadcast**]

To define an ATM map statement for an SVC, use the **atm-nsap** map-list configuration command in conjunction with the **map-list** global configuration command. The **no** form of this command removes the address.

<i>protocol</i>	One of the following keywords: appletalk , apollo , bridge , clns , decnet , ip , ipx , vines , xns .
<i>protocol-address</i>	Destination address that is being mapped to this SVC.
<i>atm-nsap-address</i>	Destination ATM NSAP address. Must be exactly 40 hexadecimal digits long and in the correct dotted format.
class	(Optional) Keyword.
<i>class-name</i>	(Optional) Name of a table that contains encapsulation-specific parameters. Such a table can be shared between maps that have the same encapsulation.
broadcast	(Optional) Indicates this map entry is to be used when the corresponding <i>protocol</i> sends broadcast packets to the interface (for example, IGRP updates).

[no] **protocol** *protocol-address* **atm-vc** *vcd* [broadcast]

To define an ATM map statement for a PVC, use the **atm-vc** map-list configuration command in conjunction with the **map-list** global configuration command. The **no** form of this command removes the address.

protocol

One of the following keywords: **appletalk**, **apollo**, **bridge**, **clns**, **decnet**, **ip**, **ipx**, **vines**, **xns**.

protocol-address

Destination address that is being mapped to this PVC.

vcd

Virtual circuit descriptor of the PVC.

broadcast

(Optional) Keyword that indicates this map entry is to be used when the corresponding *protocol* wants to send broadcast packets (such as IGRP updates) to the interface.

Provides pseudo-broadcasting support.

atmsig close atm *slot/0 vcd*

To disconnect an SVC, use the **atmsig close atm** EXEC command.

slot

Slot of the SVC to close.

vcd

Virtual circuit descriptor of the signaling PVC to close.

dxi map *protocol* *protocol-address* *vpi* *vci* [broadcast]

no dxi map *protocol* *protocol-address*

To map a protocol address to a given VPI and VCI, use the **dxi map** interface configuration command. Use the **no** form of this command to remove the mapping for that protocol and protocol address.

protocol

The bridging or protocol keyword: **apollo**, **appletalk**, **bridge**, **clns**, **decnet**, **ip**, **novell**, **vines**, or **xns**.

protocol-address

Protocol-specific address.

<i>vpi</i>	Virtual path identifier in the range 0 to 15.
<i>vci</i>	Virtual circuit identifier in the range 0 to 63.
broadcast	(Optional) Broadcasts should be forwarded to this address.

[no] dxi pvc *vpi vci* [snap** | **nlpid** | **mux**]**

Use the **dxi pvc** interface configuration command to configure multiprotocol or single protocol ATM-DXI encapsulation. The **no** form of this command disables multiprotocol ATM-DXI encapsulation.

<i>vpi</i>	ATM network virtual path identifier (VPI) of this PVC, in the range from 0 through 255. The VPI is an 8-bit field in the header of the ATM cell. The VPI value is unique only on a single interface, not throughout the ATM network (it has local significance only).
<i>vci</i>	Both <i>vpi</i> and <i>vci</i> cannot be specified as 0; if one is 0, the other cannot be 0.
snap	ATM network virtual channel identifier (VCI) of this PVC, in the range of 0 through 65535. The VCI is a 16-bit field in the header of the ATM cell. The VCI value is unique only on a single interface, not throughout the ATM network (it has local significance only).
nlpid	Both <i>vpi</i> and <i>vci</i> cannot be specified as 0; if one is 0, the other cannot be 0.
(Optional) LLC/SNAP encapsulation based on the protocol used in the packet. This keyword defines a PVC that can carry multiple network protocols. This is the default.	
(Optional) RFC 1294/1490 encapsulation. This option is provided for backward compatibility with the default encapsulation in earlier versions of the Cisco IOS.	

<i>vpi</i>	ATM network virtual path identifier (VPI) of this PVC, in the range from 0 through 255. The VPI is an 8-bit field in the header of the ATM cell. The VPI value is unique only on a single interface, not throughout the ATM network (it has local significance only).
	Both <i>vpi</i> and <i>vci</i> cannot be specified as 0; if one is 0, the other cannot be 0.
<i>vci</i>	ATM network virtual channel identifier (VCI) of this PVC, in the range of 0 through 65535. The VCI is a 16-bit field in the header of the ATM cell. The VCI value is unique only on a single interface, not throughout the ATM network (it has local significance only).
	Both <i>vpi</i> and <i>vci</i> cannot be specified as 0; if one is 0, the other cannot be 0.
snap	(Optional) LLC/SNAP encapsulation based on the protocol used in the packet. This keyword defines a PVC that can carry multiple network protocols. This is the default.
mux	(Optional) MUX encapsulation; the carried protocol is defined by the dxi map command when the PVC is set up. This keyword defines a PVC that carries only one network protocol.

[no] loopback plim

To place the AIP into loopback mode, use the **loopback plim** interface configuration command. The **no** form of this command removes the loopback.

[no] map-class *encapsulation class-name*

To define quality of service (QOS) parameters that are associated with a static map for an SVC, use the **map-class** global configuration command. The **no** form of this command deletes this class.

encapsulation Encapsulation type. One of the following:
atm, dialer, frame-relay, smds, or x25.

class-name User-assigned name of the QOS parameters table.

[no] map-group *name*

To associate an ATM map list to an interface or subinterface for either a PVC or SVC, use the **map-group** interface configuration command. The **no** form of this command removes the reference to the map list.

name Name of the map list identified by a **map-list** command.

[no] map-list *name*

To define an ATM map statement for either a PVC or SVC, use the **map-list** global configuration command. The **no** form of this command deletes this list and all associated map statements.

name Name of the map list.

show atm interface atm *slot/0*

To display ATM-specific information about an interface, use the **show atm interface atm** privileged EXEC command.

slot Slot number of the AIP.

show atm map

To display the list of all configured ATM static maps to remote hosts on an ATM network, use the **show atm map** EXEC command.

show atm traffic

To display current, global ATM traffic information to and from all ATM networks connected to the router, use the **show atm traffic** EXEC command.

show atm vc [vcid]

To display all active ATM virtual circuits (PVCs and SVCs) and traffic information, use the **show atm vc** privileged EXEC command.

vcid (Optional) Number of the virtual circuit to display information about.

show dxi map

To display all the protocol addresses mapped to a serial interface, use the **show dxi map** EXEC command.

show dxi pvc

To display the PVC statistics for a serial interface, use the **show dxi pvc** EXEC command.

show sscop

To show SSCOP details for all ATM interfaces, use the **show sscop** EXEC command.

sscop cc-timer *seconds*
no sscop cc-timer

To change the connection control timer, use the **sscop cc-timer** interface configuration command. The **no** form of this command restores the default value.

seconds Number of seconds between BGN messages. The default is 10 seconds.

[no] sscop keepalive-timer *seconds*

To change the keepalive timer, use the **sscop keepalive-timer** interface configuration command. The **no** form of this command restores the default value.

seconds Number of seconds the router waits between transmission of POLL PDUs when no SD or SDP PDUs are queued for transmission or are outstanding pending acknowledgments. The default is 30 seconds.

sscop max-cc *retries*

no sscop max-cc

To change the retry count of connection control, use the **sscop max-cc** interface configuration command. The **no** form of this command restores the default value.

retries Number of times that SSCOP will retry to transmit BGN, END, or RS PDUs as long as an acknowledgment has not been received. Valid range is 1 to 6000. The default is 10 retries.

sscop poll-timer *seconds*

no sscop poll-timer

To change the poll timer, use the **sscop poll-timer** interface configuration command. The **no** form of this command restores the default value.

seconds Number of seconds the router waits between transmissions of POLL PDUs. The default is 10 seconds.

sscop recv-window *packets*
no sscop recv-window

To change the receiver window, use the **sscop recv-window** interface configuration command. The **no** form of this command restores the default value.

packets Number of packets the interface can receive before it must send an acknowledgment to the ATM switch. Valid range is 1 to 6000. The default is 7 packets.

sscop send-window *packets*
no sscop send-window

To change the transmitter window, use the **sscop send-window** interface configuration command. The **no** form of this command restores the default value.

packets Number of packets the interface can send before it must receive an acknowledgment from the ATM switch. Valid range is 1 to 6000. The default is 7 packets.