Fast Install Guide

This Fast Install Guide lists the steps required to install the FastHub 116T. This guide assumes that you are familiar with installing and managing Ethernet hubs, and that you are aware of configuration and planning requirements of a Fast Ethernet network.

⚠️ **Caution**   If you do not have Ethernet hub experience, proceed to the "Introduction" chapter. If you would like help planning your Fast Ethernet Network, proceed to the "Planning" chapter.

Packing List

Check the FastHub 116T package. It should contain the following items:

- The FastHub 116T
- The *FastHub 116T User Guide*, this booklet
- Power cord
- Warranty package
- Four rack mount screws
- Cushioning kit: four rubber feet with instructions

Note   If any of these items are missing, notify Cisco Systems.

Fast Install Procedures

Step 1   Unpack the FastHub 116T.

Note   See the "Hardware Installation" chapter for detailed hardware installation information.

Step 2   Mount the FastHub 116T on a table, shelf, or in a rack.

Step 3   Attach the power cable, and turn on the power.

Step 4   Cable the workstations and servers to the FastHub 116T.