


FastHub 112F Connectors

This appendix describes the connectors for the FastHub 112F.

The 100Base-FX Connectors

The FastHub 112F uses standard ST connectors. The arrangement of the pins is shown in Figure B-1.

Figure B-1 100Base-FX Connector



The 100Base-FX Connectors
