



Fast Install Guide

This chapter lists the steps required to install the FastHub 116C. This section assumes you are familiar with installing and using Ethernet repeaters, and that you are aware of the configuration and planning requirements of a Fast Ethernet network.



Caution If you do not have Ethernet repeater experience, read the “Introduction” chapter. If you need help configuring or planning your network, read the “Planning” chapter.

Packing List

Check the FastHub 116C package. It should contain the following items:

- The FastHub 116C unit
- This *FastHub 116C User Guide*
- Power cord
- Warranty package
- Four rackmount screws
- Cushioning kit: four rubber feet with instructions.

Note If any of these items are missing, notify Cisco Systems.

Fast Install Procedures

The following is an abbreviated installation procedure. For a more detailed description of the installation procedures, refer to the “Installation” chapter.

To install your FastHub 116C:

- Step 1** Unpack the FastHub 116C unit.
- Step 2** Mount FastHub 116C on a table, shelf, or rack.
- Step 3** Attach the power cable and turn the power on.
- Step 4** Cable the workstations and servers to the FastHub 116C.