

## Appendix E

### Error and Status Messages

This appendix describes the three types of error and status messages returned by Workgroup Director: invalid messages, SNMP messages, and SNMP errors.

#### Invalid Error and Status Messages

The following error and status messages occur because data was entered in an invalid format.

- **valid range n1...n2**—The value entered in this field is out of range of the parameter. Enter another value within the specified range.
- **invalid IP address**—This IP address has an invalid format. Enter a 32-bit IP address using the dotted-decimal notation (a.b.c.d).
- **invalid address**—This physical address has an invalid format. Enter a 48-bit address in the following format: nn:nn:nn:nn:nn:nn.

#### SNMP Status Messages

The following error and status messages occur as a result of an SNMP request:

- **SNMP Request Started**—An SNMP request has been sent to the concentrator, switch, or adapter SNMP agent.
- **SNMP Request Completed**—The concentrator, switch, or adapter received a successful SNMP response.
- **SNMP Request Time Out**—The concentrator, switch, or adapter did not receive an SNMP response within the specified time period.
- **End of Table - Get Next to Wrap**—The end of table was reached. Use the Get Next button to wrap to the beginning of the table.

## SNMP Error Messages

The following error messages occur due to an exception that occurred when a request was processed:

- **SNMP Error - tooBig**—The SNMP agent could not fit the results of an operation into a single SNMP message.
- **SNMP Error - noSuchName**—The requested operation identified an unknown variable name.
- **SNMP Error - badValue**—The requested operation specified an incorrect syntax or value when trying to modify a variable.
- **SNMP Error - readOnly**—The requested operation tried to modify a variable that, according to the community profile, may not be written.
- **SNMP Error - genErr**—A general, unknown error.