

Troubleshooting

The FastHub 112F LEDs facilitate troubleshooting during ongoing operation. Table 4-1 displays the potential problem symptoms, possible causes, and corrective actions.

Table 4-1 Troubleshooting

Symptom	Possible Cause	Corrective Action(s)
Power LED does not come on	Power switch off	Turn on switch
	Power cord not connected	Plug in both ends of power cord
	Fuse blown	Replace fuse. If the problem recurs, contact Cisco or your authorized reseller
	Other	Contact Cisco or your authorized reseller
Link LED does not come on	No cable inserted	Insert both ends of cable into a device
	Device(s) not powered	Ensure both devices have power
	Bad cable	Replace cable with known good one
Disabled LED blinks	Device at other end malfunctioning	Investigate device at other end of cable from the disabled FastHub 112F port
	Bad cable	Replace cable with known good one

