

Apollo Domain Commands

This chapter describes the function and displays the syntax of each Apollo Domain command. For more information about defaults and usage guidelines, see the corresponding chapter of the *Router Products Command Reference* publication.

apollo access-group *access-list-name*
no apollo access-group

To apply an access list to an interface, use the **apollo access-group** interface configuration command. To remove the access list, use the **no** form of this command.

access-list-name Name of an access list to apply to the interface.

apollo access-list *access-list-name* {**deny** | **permit**}
[*firstnet*-]*lastnet.host* [*wildcard-mask*]
no apollo access-list *access-list-name*

To define an Apollo Domain access list, use the **access-list** global configuration command. To remove an access list, use the **no** form of this command.

access-list-name Name of the access list.
deny Denies access if the conditions are matched.
permit Permits access if the conditions are matched.
firstnet (Optional) Number that specifies the lower limit of a selected Apollo network range.
lastnet.host Number that specifies the upper limit of a selected Apollo network range. This is a 32-bit Apollo address consisting of a network number and a host number separated by a period. To specify all networks, use a value of -1.

wildcard-mask (Optional) A wildcard mask that uses the one bits to ignore the host part of the network address. Host bits corresponding to wildcard mask bits set to zero are used in comparisons.

apollo maximum-paths *paths*
no apollo maximum-paths

To set the maximum number of paths the router uses when sending packets, use the **apollo maximum-paths** global configuration command. To restore the default value, use the **no** form of this command.

paths Maximum number of equal-cost paths from which the router chooses. The argument *paths* can be a value from 1 to 512. The default is 1.

[no] apollo network *number*

To enable Apollo Domain routing on a particular interface, use the **apollo network** interface configuration command. To disable Apollo Domain routing on an interface, use the **no** form of this command. By default, Apollo routing is disabled.

number Network number. This is an eight-digit hexadecimal number consisting of the network address followed by the host address.

[no] apollo route *destination-network* *network.host*

To add a static route to the Apollo Domain routing table, use the **apollo route** global configuration command. To remove a route from the routing table, use the **no** form of this command.

destination-network Network to which you want to establish a static route. This is a 12-bit hexadecimal number. You can omit leading zeros.

network.host

Network address of the router to which to forward packets destined for *destination-network*. The argument *network* is a 12-bit hexadecimal number. You can omit leading zeros. The argument *host* is the host number of the target router. This is a 20-bit hexadecimal value.

[no] apollo routing *host*

To enable Apollo routing, use the **apollo routing** global configuration command. To disable Apollo routing, use the **no** form of this command. By default, Apollo routing is disabled.

host

Host number of the router. This is a five-digit hexadecimal host address that is unique across the Apollo internet.

apollo update-time *interval*

no apollo update-time

To set the interval between Apollo Domain routing updates, use the **apollo update-time** interface configuration command. To restore the default value, use the **no** form of this command.

interval

Interval, in seconds, at which Apollo Domain routing updates are sent. The minimum interval is 10 seconds, and the maximum is 2493644 seconds. The default is 30 seconds.

show apollo arp

To list the entries in the Apollo Domain ARP table, use the **show apollo arp** EXEC command.

show apollo interface [type number]

To display the status of the Apollo Domain interfaces configured in the router and the parameters configured on each interface, use the **show apollo interface** EXEC command.

type (Optional) Interface type. It can be one of the following types: asynchronous, dialer, Ethernet (IEEE 802.3), loopback, null, serial, or tunnel.
number (Optional) Interface number.

show apollo route [network]

To display the contents of the Apollo Domain routing table, use the **show apollo route** EXEC command.

network (Optional) Number of the network that the route is to. This is a 12-bit hexadecimal number.

show apollo traffic

To display information about the number and type of Apollo Domain packets transmitted and received by the router, use the **show apollo traffic** EXEC command.