

## SMDS Commands

---

This chapter describes the function and displays the syntax of each SMDS command. For more information about defaults and usage guidelines, see the corresponding chapter of the *Router Products Command Reference* publication.

**[no] arp *ip-address smds-address* smds**

Use this variation of the **arp** global configuration command to enable ARP entries for static routing over the SMDS network. Use the **no** form of this command to disable this capability.

<i>ip-address</i>	IP address of the remote router.
<i>smds-address</i>	12-digit SMDS address in the dotted notation nnnn.nnnn.nnnn (48 bits long).
<b>smds</b>	Enables ARP for SMDS.

### **encapsulation smds**

Use the **encapsulation smds** interface configuration command to enable SMDS service on the desired interface.

### **show arp**

Use the **show arp** privileged EXEC command to display the entries in the ARP table for the router.

### **show smds addresses**

Use the **show smds addresses** privileged EXEC command to display the individual addresses and the interface they are associated with.

### **show smds map**

To display all SMDS addresses that are mapped to higher-level protocol addresses, use the **show smds map** privileged EXEC command.

### **show smds traffic**

To display statistics about bad SMDS packets the router has received, use the **show smds traffic** privileged EXEC command.

### **[no] smds address *smds-address***

To specify the SMDS individual address for a particular interface, use the **smds address** interface configuration command. To remove the address from the configuration file, use the **no** form of this command.

*smds-address* Individual address provided by the SMDS service provider. This address is protocol independent.

### **smds dxi**

To enable the DXI 3.2 support, use the **smds dxi** interface configuration command. To disable the DXI 3.2 support, use the **no** form of this command.

### **[no] smds enable-arp**

To enable dynamic Address Resolution Protocol (ARP), use the **smds enable-arp** interface configuration command. The multicast address for ARP must be set before this command is issued. Once ARP has been enabled, use the **no** form of this command to disable the interface.

**[no] smds multicast** *protocol smds-address*

To assign a multicast SMDS E.164 address to a higher-level protocol, use the **smds multicast** interface configuration command. To remove an assigned multicast address, use the **no** form of this command with the appropriate address.

<i>protocol</i>	Protocol type. See this command in the <i>Router Products Command Reference</i> publication for a list of supported values.
<i>smds-address</i>	SMDS address. Because SMDS does not incorporate broadcast addressing, a group address for a particular protocol must be defined to serve the broadcast function.

**[no] smds multicast arp** *smds-address [ip-address mask]*

To map the SMDS address to a multicast address, use the **smds multicast arp** interface configuration command. Use the **no** form of this command to disable this feature.

<i>smds-address</i>	SMDS address in E.164 format.
<i>ip-address</i>	(Optional) IP address.
<i>mask</i>	(Optional) Subnet mask for the IP address.

**[no] smds multicast bridge** *smds-address*

To enable spanning tree updates, use the **smds multicast bridge** interface configuration command. Use the **no** form of this command to disable this function.

<i>smds-address</i>	SMDS multicast address in E.164 format.
---------------------	---

## SMDS Commands

**[no] smds multicast ip** *smds-address* [*ip-address mask*]

To map an SMDS group address to a secondary IP address, use the **smds multicast ip** interface configuration command. Use the **no** form of this command to remove the address map.

<i>smds-address</i>	SMDS address in E.164 format.
<i>ip-address</i>	(Optional) IP address.
<i>mask</i>	(Optional) Subnet mask for the IP address.

**[no] smds static-map** *protocol protocol-address smds-address*  
**[broadcast]**

To configure a static map between an individual SMDS address and a higher-level protocol address, use the **smds static-map** interface configuration command. Use the **no** form of this command with the appropriate arguments to remove the map.

<i>protocol</i>	Protocol. It can be one of the following values: <b>appletalk, clns, decnet, ip, ipx, vines, or xns.</b>
<i>protocol-address</i>	Address of the higher-level protocol.
<i>smds-address</i>	SMDS address, to complete the mapping.
<b>broadcast</b>	(Optional) Marks the specified protocol address as a candidate for broadcast packets. All broadcast requests will be sent to the unicast SMDS address.